


Operator's and Service Manual

Avery Dennison
SNAP™ 700 Printer
SNAP™ 700 RFID Printer



WARNING

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:

- 1) this device may not cause harmful interference, and
- 2) this device must accept any interference that may cause undesired operations.

This Class A digital apparatus meets all requirements of the Canadian Interference Causing Equipment Regulations. Cet appareil numérique de la classe A respecte toutes les exigences du Règlement sur le matériel brouilleur du Canada



Declaration Of Conformity

according to EN ISO/IEC 17050-1:2004

Manufacturer's Name and Address

Avery Dennison RIS LLC
(dba Avery Dennison RBIS or dba Avery Dennison)
170 Monarch Lane
Miamisburg, Ohio 45342 U.S.A.
Phone: 937-865-2123

Product Information

Product Name:	Thermal Printer, Label
Model Number:	SNAP 700
Trademarks:	Avery Dennison®
Optionally Containing:	RFID

Type of Test	Standard Used
Low Voltage Directive (LVD) – 2014/35/EU	EN 60950-1:2006+A11:2009+A1:2010+A12:2011+A2:2013
EMC Directive – 2014/30/EU	EN 55032:2012/AC: 2013, Class A EN 55024:2010 EN 61000-3-2:2014 EN 61000-3-3:2013
Machinery Directive – 2006/42/EC	EN 60204-1 EN ISO 12100:2010


The model number listed represents a worst case configuration. This model number is the main product identifier in the regulatory compliance documentation and test reports.

This device was designed and constructed according to the fundamental safety and health requirements of the following EU directives:

- WEEE Directive – 2012/19/EU
- RoHS Directive – 2011/65/EU
- REACH Directive - Regulation (EC) No. 1907/2006

1 February 2017

Date



Frank Dominguez
Regulatory Engineer

TCSNAP700CD Rev. AH 2/17
<http://www.monarch.averydennison.com/support/regulatory.asp>



Table of Contents

1.0	INTRODUCTION	9
2.0	SAFETY INSTRUCTIONS	11
3.0	INSTALLATION	13
3.1	Preparing for the installation	13
3.1.1	AC Power Line	13
3.1.2	Location Considerations	13
3.1.3	PC Requirements	14
3.1.4	User Safety	15
3.2	Receiving	15
3.3	Unpacking	16
3.3.1	Removing the printer from the carton	16
3.3.2	Inspection /Inventory Checklist	17
3.3.3	Downloading Support Documentation	18
3.3.4	Disassembly and Disposal	18
3.4	Printer Description	19
3.4.1	Component Descriptions	19
3.4.2	Printer Configurations	20
3.5	Printer Setup	21
3.5.1	Attaching the Stacker	21
3.5.2	Attaching the Unwind Assembly	22
3.5.3	Checking the Main Fuse Configuration	22
3.5.4	Installing the Power Cord	23
3.6	Communications Cable Installation	24
3.6.1	Serial Cable	24
3.6.2	USB Cable	24
3.7	Networking Setup	25
3.7.1	BIOS settings	25
3.7.2	Connecting the networking cable	25
3.7.3	Setting the Printer IP Address	26
3.8	PCMate Platinum Software Installation	27
3.9	Printing a Test Label	27
3.9.1	Loading Supplies	27
3.9.2	Turning the Printer on	27

3.9.3	Selecting the Test Format	28
3.9.4	Printing the Test Labels	28
4.0	OPERATION	29
4.1	Loading Supplies	29
4.1.1	Installing Ink to the Top Ink Supply Station	29
4.1.2	Installing Ink to the Bottom Ink Supply Station	32
4.1.3	Loading the Stock	32
4.1.4	Butt Splice	34
4.1.5	Threading Diagrams	35
4.2	Sending a Print Job to the Printer	36
4.3	Printing Labels	36
4.3.1	The Control Panel	36
4.3.2	Printing	37
4.3.3	Handling the Leader	37
4.3.4	Feeding the stock	37
4.3.5	Errors	37
4.3.6	RFID Printed Errors	38
4.3.7	End of Day	38
4.3.8	Clearing Print Jobs	38
4.4	Using Pre-Printed Stock	39
4.4.1	Selecting the Sensor	39
4.4.2	Aligning the Stock to the Sensor	39
4.4.3	Aligning the Sensor to the Stock	40
4.5	Option Menu System	40
4.5.1	Running Test Patterns	41
4.5.2	Setting / Adjusting Voice Button Volume	43
5.0	MAKING ADJUSTMENTS	45
5.1	Print Head Adjustments	45
5.1.1	Adjusting Print Head Pressure	45
5.1.2	Adjusting Density (Darkness)	46
5.2	Adjusting the Stacker	46
5.2.1	Stacker Position	46
5.2.2	Toggle Switch	46
5.2.3	Stacker Angle	47
5.2.4	Platform	47
5.2.5	Static brush	48
5.3	Virtual Control Panel	49
5.3.1	Introduction	49
5.3.2	Changing Printer Settings in PCMate	50
5.3.3	Print/Cut Adjust Tab	51
5.3.4	Selecting the Printer Language	52
5.3.5	Setting the Date and Time	52
5.3.6	Enabling or Disabling the Cutter	53

5.3.7	Selecting the Print Speed	53
5.3.8	Selecting the Flagging Mode	53
5.3.9	Selecting the Sense Mark Type	54
5.3.10	Setting the Default Transfer	54
5.3.11	Viewing the Life Counts	55
5.3.12	Firmware	55
5.3.13	Print Quality	56
5.3.14	Other information on VCP	56
5.4	Web Server	57
5.4.1	Viewing and Changing the Printer Settings	57
5.4.2	Converting the DHCP Address to a Static Address	58
5.4.3	Resetting the Printer to DHCP Mode	59
5.4.4	Troubleshooting the Network Connection	59
6.0	MAINTENANCE	60
6.1	Print Head Cleaning and Handling	60
6.1.1	Handling Techniques	60
6.1.2	Cleaning Procedures	61
6.2	Print Head Replacement	62
6.3	Lubrication	64
6.4	Rotary Knife Assembly	64
6.4.1	Removing and Replacing the Knife Assembly	65
6.4.2	Adjust the Knife Home Position	68
6.5	Rubber Roller Replacement	68
7.0	SERVICE ADJUSTMENTS	69
7.1	Stock (Web) Guide Position	69
7.2	Stock (Web) Guide Width Adjustments	69
7.3	Stock Feed	69
7.4	Knife Shear Adjustment	70
8.0	UPGRADING THE PRINTER FIRMWARE	72
8.1	Introduction	72
8.2	Selecting the UPG file	72
8.3	Getting the UPG file	72
8.3.1	Getting UPG file using D2Comm	72
8.3.2	Getting UPG file without using D2Comm	73
8.4	Performing the Upgrade	73
8.4.1	Unzipping the file	73
8.4.2	Upgrading through PCMate	74
8.4.3	Upgrading through USB Flash Drive	77
8.4.4	Upgrading through the Webserver	78

9.0 ELECTRICAL TROUBLESHOOTING	81
9.1 Power Up / Sign On / Communications	81
9.2 Stock / Ink Advance	83
9.3 Print	84
9.4 Cut / Stack	86
9.5 Printer Errors	87
10.0 MECHANICAL TROUBLESHOOTING	93
10.1 Stock	93
10.2 Ink	94
10.3 Print	94
10.4 Knife	94
10.5 Stacker	95
11.0 APPENDICES	96
11.1 Fuse Configuration	96
11.2 Ink and Stock Transfer Types	97
11.3 Printer Specifications	99
11.4 Factory / Field Installation of Top Sensor Assemblies	101
11.4.1 Installation Procedure	101
11.5 Programming the Contrast Sensors	105
11.5.1 Programming the Contrast Sensor	106
11.5.2 Programming the Color Contrast Sensor	107
11.6 Factory / Field Installation of High Speed Verifier Assembly	109
11.6.1 Installation Procedure - Mechanical	109
11.6.2 Installation Procedure - Electrical	111
11.6.3 Installation – Rear Cover	112
11.7 Warranty Policy	113
11.7.1 Service	114
11.8 Option Menu System Flowchart	115
12.0 ELECTRICAL DRAWINGS	116
12.1 Electrical System Schematic	117
12.2 Harness Connections	118
13.0 MECHANICAL ASSEMBLY DRAWINGS	119
13.1 Unwind Assembly	120

13.2	Unwind Assembly RFID 3" / 4"	122
13.3	Unwind Motor Assembly	124
13.4	Decurler Assembly	126
13.5	Web Guide Assembly	128
13.6	Sensor Tray Assembly	130
13.7	Sensor Tray RFID Assembly	132
13.8	Top Print Head Assembly	134
13.9	Bottom Print Head Assembly	136
13.10	Print Head Assembly	138
13.11	Platen Roller Assembly	140
13.12	Ink Arbor Assembly	142
13.13	Ink Unwind / Rewind Motor(s) Assembly	144
13.14	Drive Assembly	146
13.15	Knife Assembly	148
13.16	Nip Roller Assembly	150
13.17	Knife / Drive Motors Assembly	152
13.18	Knife Drive Motor Assembly RFID	154
13.19	RFID Reader Assembly	156
13.20	Covers Assembly	158
13.21	Cooling Fans Assembly	160
13.22	Stacker Assembly (Sheet 1 of 2)	162
13.23	Stacker Assembly (Sheet 2 of 2)	164
14.0	ADDENDUM I – HANDLING PROCEDURES	166
15.0	ADDENDUM II – SHORT FEED	168
15.1	Short Feed O-Ring Replacement	168
15.2	Short Feed Assembly	169
15.3	Short Feed Part List	170
16.0	REVISION RECORD	172

1.0 Introduction

VERY DENNISON has designed the SNAP™ 700 printer for simple installation, easy operation, and dependability. Use your printer to produce two-sided, brand/care labels, paper hang tags and self-adhesive stickers for your apparel, footwear, or other products needing identification. Printing up to a speed of up to 7 inches (178 mm) per second for care labels and 12 inches (305mm) per second for tags and stickers, (supply dependent) the SNAP 700 printer features quick change-outs of inks and tapes, multilingual voice prompts, and easy operating system updates. Finally, the SNAP 700 printer supports various options including RFID.

The SNAP 700 multiple head printer can have two different head configurations when ordered. This manual covers both configurations.

This manual guides the printer operator as an easy-to-use, quick-reference guide. It contains procedures for receiving, handling, set-up, installation, operation, and maintenance of the SNAP 700 printer.

Please read this section of the manual to familiarize yourself with the printer and to guide you through the initial receiving and set-up of your new SNAP 700 printer. Throughout this manual, a system of NOTES, CAUTIONS, and WARNINGS identify key information to ensure your personal safety and to proper printer operation. Please review these carefully.

We also strongly suggest that you watch the 17-minute training video, which is available on the Avery Dennison support web site. Refer to the documentation included with the printer for more details.



NOTES call attention to information that is especially significant to understanding and operating the equipment.



CAUTION notices inform you of actions or situations in which the printer might be damaged.




WARNING notices describe situations in which lack of attention or insufficient equipment knowledge could cause either personal injury or damage to the printer.

Page intentionally left blank

2.0 Safety Instructions

- Follow all of the safety requirements and procedures established for your facility.
- Turn off the power to the printer before cleaning, servicing, or replacing any components.
- You do not have to turn off the power when loading or changing supplies.
- Follow all cautions and instructions marked on the product
- There are hazardous moving parts in the printer. Service should be performed only by trained service personnel.
- All covers and guards must be in place when operating the printer and should be removed only by trained service personnel.
- Do not push objects of any kind through openings in the equipment. Dangerous energy might be present and cause fire, electric shock, or damage to the equipment.
- Do not block or cover the openings of the equipment.
- Do not place the equipment near a radiator or heat register. This could cause the product to overheat.
- Turn off the printer and disconnect the power cord before servicing the printer.
- Operators should read and understand the Operators manual before operating the printer
- If the printer operates improperly or fails to respond to commands, turn the printer off using the power switch. If the problem continues to occur, obtain service for the printer.
- The AC mains supply for the printer should be properly grounded and provide overcurrent protection as required to meet all local electrical and building codes.
- The AC mains supply for the printer should be properly grounded and should meet all local electrical and building codes and provide overcurrent protection as required.
- The AC mains supply for the printer should be properly grounded and should meet all local electrical and building codes and provide overcurrent protection as required
- Do not remove, deface, or defeat any safety guards or warning labels.
- Do not operate the printer with any parts missing or broken.
- For information about supply compatibility or environmental information, contact your local Avery Dennison Customer Service.

- The printer has been designed to be as safe as possible. However, there are moving parts during the normal operation of the printer. Obey all warning labels and safety instructions during operation.



CAUTION: The SNAP 500 printer has some pinch points which have safeguards design in. AVERY DENNISON strongly recommends that you do not modify or bypass these safeguards.



CAUTION: Danger of explosion if battery is incorrectly replaced. Return product to Avery Dennison for proper replacement and disposal. Call 1 – 800 – 543 – 6650



Warning: There are hazardous moving parts at the print head station. Keep hair, loose garments, jewelry and fingers away.

3.0 Installation

3.1 Preparing for the installation

3.1.1 AC Power Line



NOTE: AVERY DENNISON requires that the minimum electrical service be 10 Amps @ 115VAC or 6 Amps @ 230VAC. This will allow you to plug the SNAP 700 printer, PC, and any additional support or service equipment into the same service. We highly recommend that the printer and its accessories be on a dedicated circuit.

The electrical service supplying power to the SNAP 700 printer or to peripheral equipment connected to the SNAP 700 printer should meet standard electrical code practices, including proper grounding and neutrals.

3.1.2 Location Considerations

The SNAP 700 printer weighs 60 pounds (27.2 Kg) and requires a table of sufficient quality and strength to handle this load. The printer requires an area of approximately 72" wide x 30" deep x 32" high (1.8 m x 76 cm x 81 cm). The host PC (if used) and any printer options will increase the required area. AVERY DENNISON recommends using an industrial type worktable. Refer to Figure 1 below.

The SNAP 700 printer is designed for easy operator accessibility to the printer controls and components. Select your SNAP 700 printer's location to meet the following criteria:

1. Physical demands on the operator will dictate proper height of the table supporting the printer. Ensure the operator has comfortable access to the printer. Refer to Figure 1.
2. Allow enough space for smooth flow of materials that the operator will load on the printer as well as space for processing the finished product from the printer.
3. While AVERY DENNISON has designed the printer to be reasonably quiet, select an area where repetitious noise from printing and cutting processes is acceptable. This is not an office space printer, it's a production machine.



CAUTION: Each customer must take responsibility to ensure the workstation created for the SNAP 700 printer meets the recommended requirements to ensure optimal operation of the printer.




Figure 1. Recommended Workstation Layout

3.1.3 PC Requirements

Most customers use a personal computer to download information to the SNAP 700 printer. The printer can be connected to any type of computer capable of sending the AVERY DENNISON Command Language, or PCL.

PCMate Platinum tag and label printing software supports the new virtual control panel feature when using the SNAP 700 printer. PCMate features higher communication speeds of the SNAP 700. Finally, it can deliver firmware upgrades from the Internet.

PCMate Platinum requires the following minimum PC system:

- IBM® PC or Compatible
- Microsoft Windows® XP, 7 or later (check for latest version of Windows)
- At least 2 Gigabytes of RAM
- At least 10 Gigabyte of available disk space
- Pentium III or later processor, 800Mhz
- Monitor with 1024 x 768 resolution
- CD ROM drive
- Internet Connection to access software upgrades and remote diagnostics

Refer to your PCMate Platinum user's manual for proper installation procedures.

3.1.4 User Safety

1. Follow all of the safety requirements and procedures established for your facility.
2. Turn off the power to the printer before cleaning, servicing, or replacing any components.
3. You do not have to turn off the power when loading or changing supplies.



CAUTION: The SNAP 700 printer has some pinch points which have safeguards designed in. AVERY DENNISON strongly recommends that you do not modify or bypass these safeguards.



CAUTION: Danger of explosion if battery is incorrectly replaced. Return product to Avery Dennison for proper replacement and disposal. Call 1 – 800 – 543 – 6650



Warning: There are hazardous moving parts at the print head station. Keep hair, loose garments, jewelry and fingers away.

3.2 Receiving

The SNAP 700 printer's shipping carton weighs 90 pounds (40.8 Kg). The carton is large and specially made to protect the printer. It may be awkward or difficult to move by hand to its installation location.



CAUTION: Do not remove the printer from the carton or unpack in the shipping / receiving department. Move the carton to the installation location.

- Move the SNAP 700 printers with a forklift, fork cart or handcart to its intended location. Use one of these handling devices to more easily and safely move the printer. Leave the printer in the carton while moving it to protect it.
- The stacker and any other accessories purchased for the printer may be shipped separately.

3.3 Unpacking

3.3.1 Removing the printer from the carton

1. Open the carton by removing the banding straps.
2. Cut the tape seam on the top of the carton.
3. Remove top foam-packing layer (see Figure 2A).
4. Remove any individual pack components like the supply unwind arbor.



Figure 2A – Shipping Carton



CAUTION: Do not discard any of the packing / shipping material in case you have to move the printer to another location or return it to AVERY DENNISON for service.

5. The printer has been wrapped with plastic to protect the printer from the packing material and moisture.
6. It requires 2 people to remove the printer from the carton.



Figure B

7. Lift the outer packing sleeve from the base (see Figure B) above.
8. Unpack the unwind arbor from its box and place it on the workstation table next to the printer. Refer to Section 2.5.6 Attaching the Unwind Assembly & Refer to Section 2.5.1, Attaching the Stacker.



CAUTION: Lifting the printer from any component other than case or stacker supports can damage the printer and cause needless start up delays.




Figure 2B: Lift Locations

3.3.2 Inspection /Inventory Checklist

1. Inspect the printer for any damage that may have occurred from shipping.
2. Check the SNAP 700 printer shipping carton to be sure the following items are also included with your printer.
 - ☐ Serial Cable
 - ☐ A quick-disconnect power cord for 115-Volt printer)
 - ☐ Unwind Assembly
3. If you see obvious damage to the printer, or if any items listed above are missing, contact AVERY DENNISON for further instructions.
 - In the U.S.A., call (937) 865-2123, select option for Customer Service.
 - Outside the U.S.A., please contact your local AVERY DENNISON supplier.



CAUTION: Each customer must take responsibility to ensure the workstation created for the SNAP 500 printer meets the recommended requirements to ensure optimal operation of the printer.

3.3.3 Downloading Support Documentation

1. Go to <http://pfs.averydennison.com/en/home/support.html>.
2. PCMate Platinum is available from this page.
3. For printer related material, click on the link called “Manuals and Status Codes”
4. From the drop down under “Apparel Model Search (SNAP 500, SNAP 700 and other printers) select “SNAP 700”.
 - ☐ SNAP printer firmware
 - ☐ Instructional videos
 - ☐ SNAP 700 printer User's Manual

3.3.4 Disassembly and Disposal

1. No special steps are needed to decommission the printer.
2. Remove stock and ink and disconnect the power cord and communication cable(s);
3. Dispose of the printer in accordance with local laws and ordinances.

3.4 Printer Description

3.4.1 Component Descriptions

Shown below are the important parts of the SNAP 700 Printer. Please take a moment to familiarize yourself with the printer.




Figure 3. SNAP 700 Printer



NOTE: Please take some time to become familiar with the printer's major components and their functions. Refer to Figure 3.

- **The Stock Unwind Arbor** holds the supply roll. By rotating the outer knob clockwise or counterclockwise, you can adjust the Arbor to accommodate stocks ranging from ½ inch - 5 inches (12.7 mm - 127 mm) wide. The arbor auto-centers the stock through the printer. Metal fingers extend to hold the supply roll in place. This allows back tension which keeps the stock centered through the printer.
- **The Stock (Web) Guide** guides the stock through the printer and is adjusted by rotating the black knob.
- **The Upper and Lower Print Stations** house the print head assemblies. They have knobs for adjusting print head pressure and print density to

control the print quality.

- **The Upper and Lower Ink Arbors** are adjusted using the black knob on the end of the arbor. To open up and close down the self-center arbor to the ink cores rotate the knob. Do not over tighten onto the core to hold them in place. They accommodate ink rolls ranging from 1 inch (25mm) to 5 inches (127 mm) cores.
- **A Rotary Knife Assembly** comes with printer. When printing woven tapes, use a Sonic Knife accessory option that provides ultrasonic cutting and sealing.
- **The Stacker** collects the finished, printed labels. You can adjust it to accommodate a variety of label stocks and short or long labels. Once the stacker reaches the bottom, the printer will stop, indicate the stacker is full, and allow you to remove the labels.
- **The Control Panel** with buttons and LED's indicate printer status and information about specific jobs.



WARNING: This is a class A product. In a domestic environment this product may cause radio interference in which case the user may be required to take adequate measures.

3.4.2 Printer Configurations

The Snap 700 comes in 2 configurations:

- **1 over 1** – The Snap 700 1 over 1 features one upper print head over one lower print head, capable of printing a two sided label.
- **1 over 0** – The Snap 700 1 over 0 features one print head on top only.

3.5 Printer Setup

3.5.1 Attaching the Stacker




Figure 4. Rotary Knife and Stacker

The stacker and knife are two separate assemblies that can be installed and/or replaced easily and quickly. For information on adjusting the stacker, refer to Section 4.2.

1. Locate the two shafts on the printer below the Auxiliary Feed and Knife assembly (see Figure 4).
2. Slide the stacker onto the two shafts until the backside of the stacker is beyond the stock size to be run.



NOTE: Be sure to slide the top of the stacker behind the Nip Roller stripping plate.

3. With the power off, connect the stacker cable extending from the bottom of the stacker assembly into the larger connector on the right side of the printer. Rotating the connector and applying light pressure inward will help engage the connectors.



NOTE: There is a sleeve on the connector that will snap when the connector is fully engaged with the mating connector. The two cables will slide into each other only when the connectors are properly aligned with each other.

3.5.2 Attaching the Unwind Assembly




Figure 5A: Unwind Assembly Installation

The unwind assembly is shipped detached from the printer to prevent damage during shipping.

1. The unwind assembly is easily attached by sliding the shaft on the assembly into the receiving shaft mounted on the printer.
2. Line up the holes in the assembly shaft and receiving shaft and insert provided Philips head sem screw and tighten.

3.5.3 Checking the Main Fuse Configuration



WARNING: Before powering on the printer, you must check to be sure the main fuses on the AC power receptacle are set for the appropriate voltage for your location (Line voltage of 90-132VAC @ 50-60Hz, single phase or 180-265VAC @ 50-60Hz, single phase).

The main fuse(s) on the SNAP 700 printers are located inside the AC power entry receptacle on the backside of the printer (see Figure 5). The AC power entry has a fuse drawer that holds the fuse(s) and selects the appropriate line voltage.

1. Look at the line voltage level shown in the window on the back of the printer (see Figure 1). If the number in the window matches the appropriate voltage for your location, you can proceed with setting up your printer.

2. If the line voltage does not match the voltage for your location, contact your local AVERY DENNISON supplier. To change the Fuse Configuration, see Appendix 1.
- In the U.S.A., call (937) 865-2123.
 - Outside the U.S.A., please contact your local AVERY DENNISON supplier.



WARNING: Some printers require internal changes when switching the line (mains) voltage from 115V to 230V. Refer to Appendix 1 for instructions. Failure to follow the instructions may result in damage to the printer.



CAUTION: If the number in the window DOES NOT match the AC power line intended to be supplied to the printer, DO NOT plug in the power cord.



WARNING: Attempting to open the AC power entry with the AC power cord already inserted will damage the AC entry.



Figure 5. Right Side of Printer – Rear View

3.5.4 Installing the Power Cord

A quick-disconnect power cord is shipped with each 115V printer. The cord for 115V printers will use the standard three-prong plug used in the U.S.A.

If a power cord is not supplied with your printer, and your printer is operating at a rating other than 115V, you will need to obtain a power cord for your voltage application. The power cord should have an IEC-320-C13 plug on one end and the appropriate plug for your power receptacle at the other end.

1. Locate the AC power entry receptacle on the backside of the printer just below the power switch (see Figure 5).
2. Plug the power cord into the AC power entry receptacle.

3.6 Communications Cable Installation

Use one of the following interface cable options:

- Null-modem serial cable – Part number 05581139 connector
- USB / Serial adapter – Part number 05581140
- Ethernet adapter – Part number 05591105. ASUS, BCM, or Advantech motherboards support the Ethernet port on the printer so the Ethernet adapter is not required.

3.6.1 Serial Cable

1. Locate the communication cable connectors on the backside of the printer (see Figure 6).
2. Plug in the serial cable connection to the serial port.

The default serial port setup in the printer is 115,200 baud, no parity, 8 data bits, 1 stop bit.




Figure 6: Rear View of the Printer

3.6.2 USB Cable

1. Use either the USB option card if higher download speeds are required for the extra expense of the option, or
2. USB to Serial adapter, if the USB connector is needed and serial download speed is acceptable.

3.7 Networking Setup

The recommended network setup is through a Static IP address. Once an IP address has been set, the operator can then view and change the printer settings through the SNAP webserver using a browser on any computer on the network. Most of the functionality of the VCP in PCMate is available through the web server. See section 5.4 for the webserver.

3.7.1 BIOS settings


The Advantech motherboard requires no updates to the BIOS.

BCM motherboard requires the following updates to use the Ethernet port on the printer's motherboard.


- Connect a video monitor to the video port and a keyboard to the PS/2 connector on the printer.
- Restart the printer and press the “**DEL**” key to cause the printer to enter the CMOS Setup Utility.
- Arrow down to “Integrated Peripherals”, press **Enter**
- For GbE Controller set to “ENABLE”.
- For 82573 Controller set to “ENABLE”.
- Press F10, the **Enter** (OK) to save.
- Restart the printer.

3.7.2 Connecting the networking cable

Older motherboards:



Newer motherboard:



3.7.3 Setting the Printer IP Address

DHCP process may take some time so wait at least one minute after the printer finishes its initialization with the "Ready" light is on steady before continuing. Do this only the first time a printer connects to the network.

1. Contact your Network Administrator to obtain a static IP address.
2. The default mode is DHCP mode. When attached to the network, the printer will obtain a DHCP address from the network.
3. Find the DHCP address by printing a Network ID Test Label.
 - Press and hold the Voice Button until the printer says "Press Start for Test Patterns."
 - Press the Start Button
 - Press the Voice Button until you hear "Press Start for Custom Test Pattern 1."
 - Ensure only the top printhead is open.
 - Press the Start Button
 - Find the IP address on the resulting label.

SNAP Printer Configuration	
Model	500
SW Version	3.36.15.10
IP Address	172.18.1.193

4. Use a browser such as Internet Explorer and enter the printer's IP address to access the printer's webserver. Enter the static IP address as described in section 5.4.2.
5. If moving to another network, set the printer back into DHCP mode. See section 5.4.3 for instructions using the webserver.
6. See section 5.4.4 for troubleshooting tips on the network connection.

If no IP address prints on the Network ID Test Label, the printer may not



have completed the DHCP process. Wait a few minutes and try again.

If there is still a problem, make sure the network cable is connected proper and check the other network connections.

If you still cannot obtain a DHCP address, try resetting the printer to DHCP mode as described in section 5.4.3.

Finally, set the static IP address manually and test the network connect as described above.

3.8 PCMate Platinum Software Installation

The software used to drive the AVERY DENNISON family of printers is covered in a separate manual. The PCMate Platinum software is a Windows® application used to create designs for the SNAP 500 printer as well as all other AVERY DENNISON printers.

3.9 Printing a Test Label

3.9.1 Loading Supplies

Before you can print a test label, the printer must be loaded with tape and ink. Refer to section 4.1 for instructions on loading the tape and ink.

3.9.2 Turning the Printer on

1. Turn the power switch on. The power switch is located on the back of the printer, just above the power cord.
2. The four lights on the Printer Control Panel will come on for a few seconds, and then all four lights will start to flash. This indicates that the printer is performing its internal diagnostic tests. After several seconds, the lights will stop flashing and the Ready light will come on. This indicates that the printer is ready.



NOTE: During the power sequence the knife will cycle backwards 1 time to find home and there will be an audible bell as the printer powers up.

3. If any problems occur, Troubleshooting Sections.

3.9.3 Selecting the Test Format

There are four test formats built into the printer. These are selected using the Option Menu System. The steps below describe how to select one of the test formats. For more information on the Option Menu System, see section 3.4.



When the instructions say to press a button, press the button for a short time and release it. When the instructions say to press and hold a button, press the button and hold it down until the printer responds.

When you are in the Option Menu System, you can get out by pressing and holding the Voice button until the printer says "Returning to print mode."

1. Press and hold the Voice button until the printer says "Press Start for Test Patterns."
2. Press the Start button. The printer will say "Press Start for Narrow Setup Test Pattern." If you want to print test pattern, press the Start Button then go to step 3.

If you want to print Wide Setup Test Pattern, press the Voice button. The printer will say "Press Start for Wide Setup Test Pattern." If you want to print this test pattern Press the Start button then go to step 3.

If you want to print Custom Test Pattern 1, press the Voice button. The printer will say "Press Start for Custom Test Pattern 1". If you want to print this pattern Press the Start button then go to step 3.

If you want to print Custom Test Pattern 2, press the Voice button. The printer will say "Press Start for Custom Test Pattern 2" If you want this test pattern press Start then go to step 3.

3. The printer will say "Ready to print Narrow test pattern (or will say wide, or custom test pattern 1, or 2). Returning to print mode." At this time the Data light will come on. The printer is now ready to print the test labels.
4. Ensure you have care label stock and thermal transfer ink ribbon loaded on the top and bottom printing stations.

3.9.4 Printing the Test Labels

- Press the Start button. The stacker (if installed) will move the platform to its start position and the printer will begin printing the test labels.
- If any problems occur, either the Supply or Error light will come on. If this happens, press the Voice button and the printer will say a message telling what the problem is. Correct the problem and press the Start button again. Repeat this until the printer runs continuously.
- If you can't get the printer to run, refer to sections 9 and 10 for troubleshooting.

4.0 Operation

4.1 Loading Supplies

Your SNAP 700 printer is designed with upper and optional lower ink supply stations. . The ink supply station setup is dictated by the option of the printer your ordered. There is no way to change this setup at your location.

The ink arbors have a self-center guide to locate the roll of ink to ensure smooth tracking through the machine.

The ink cores have splines on their inside surfaces. These splines align with the grooves in the ink arbors. Splines allow the printer to control the tension of the ink ribbon during printing, minimizing wrinkling and optimizing print quality.



NOTE: Only use the white plastic cores on the SNAP printers. If you have a black plastic core they are design for the Avery Dennison 9800 series printers.

4.1.1 Installing Ink to the Top Ink Supply Station

1. Install an empty ink core on the upper ink rewind arbor. It is important that the core be the same width or wider as the core of the ink being used.



NOTE: The empty ink core should be the same width as the ink supply roll.

- a. Rotate the core slightly to align the splines and grooves on the arbor. Slide it gently onto the arbor until it contacts the back core stop.
- b. If the front core locator is not exposed turn the black knob on the end of the arbor counterclockwise to bring it past the end of the core. To clamp the core rotate the black knob clockwise to center the core on the arbor. See Figure 7.



CAUTION: Do not over tighten the core locators. Little to no pressure is needed to keep the core centered. Over tightening can damage the plastic stops.

CAUTION: To avoid damaging the print head, the ink supply roll should be ¼ inch (6 mm) wider than the stock.




Figure 7. Upper Ink Supply and Print Stations - Unloaded



NOTE: The ink system is designed to rewind one roll of ink at a time. When the rewind core is full, replace it with an empty ink core. Do not try to add a second roll to the first rewind core, since it will not track through the printer correctly and will result in poor print quality.

2. Remove the plastic packaging around the roll of ink and install it on the ink supply arbor. Ensure that the leading edge is pointing toward the Stock Arbor.



NOTE: For best results, leave the ink roll wrapped in plastic until you are ready to use it in the printer.

3. Open the print roller (See Figure 8).
4. Pull the ink down and to the right, beneath the turn bar, between the upper print roller and the upper print station, toward the stacker side of the upper ink rewind arbor.




Figure 8. Upper and Lower Ink Supply and Print Stations - Loaded

4. Fasten the ink supply to the rewind core.
 - a. If you are using a new roll of ink, the leader you are advancing through the machine already has adhesive on it. Press the leader onto the rewind core until it sticks to the core.
 - b. If you are installing a partially used roll of ink, you must first attach a small piece of tape to the leading end of the ink roll. Then, tape the end to the ink on the rewind core.
5. Wind the core for several turns to make sure the ink tracks flat as it is pulled through the printer.
6. To remove an ink core from the arbor, turn the black knob at the end of the ink arbor counterclockwise and slide the core from the arbor. Save the empty core to be used as the next rewind core.

4.1.2 Installing Ink to the Bottom Ink Supply Station

Installing Ink on the Bottom Print Station is done in the same way as the Top Print Station, except that the ink runs up over the Turn bar, across the print head to the rewind arbor.

4.1.3 Loading the Stock

Before loading a roll of stock, you will need to be familiar with the following parts of the SNAP 700 printer (Refer to Figures 9 and 10).

The **Stock Arbor** is designed to clamp the core of the stock supply rolls to hold them in place during printing operations. This function provides back tension which helps keep the stock straight while it moves to the center of the print head. By rotating the stock arbor knob, you can adjust for roll widths ranging in size from ½ inch to 5 inches (12.7 mm to 127 mm). This helps keep the stock straight while it moves to the center of the print head. To function properly, the stock roll must be wound firmly and centered on the core with no telescoping of the roll. There are no other adjustments to the stock arbor.

The **Stock (Web) Guide** is located between the Stock Arbor and Sensor Module Station to guides the stock through the machine toward the center of the print head. The black knob located at the end of the web guide controls the width of the guides. Turning the knob clockwise will widen the web guides, while counterclockwise turns will narrow the web guides.

The **Upper and Lower Print Stations** on the SNAP 700 printer are stationary. The rollers swing open and closed for threading and printing. These rollers are held in position for printing with latches on both the inside and outside end of the rollers.



NOTE: If you are printing two-sided labels, both print rollers must be closed in order for the printer to operate. If a two-sided label design is sent to the printer and the lower print roller is open, the Error LED will light up and the printer will stop. If you are printing single-sided labels, the lower print roller should remain open so the ink rolls will not rotate.

The **Stock Feed** is the assembly located in front of the knife. The Feed has a knob, which is used to manually advance the material through the knife, the nip roller, and into the stacker. (See figure 10)

New rolls of Supply Stock are sealed and packaged individually. When you are ready to load the stock, remove the packaging and follow the steps below.

1. Remove the tape holding the end of the supply stock to the outer part of the roll. To avoid damaging the rollers or print heads, use scissors to cut off any portion of the supply stock that has adhesive on it.
2. Rotate the unwind knob clockwise to retract the “fingers”. Open the assembly so the back locator hub and front locking fingers are wider than the material.

3. To install the stock supply roll, begin with the leading end at the top of the roll pulling off towards the stacker.
4. Slide the stock roll onto the Stock Arbor (see Figure 9).
5. Rotate the Stock Arbor knob counter-clockwise quickly to extend the fingers that hold the supply roll in place.
6. With all print rollers in the open position, pull the stock from the top of the supply roll, and over the Decurler Roller.




Figure 9. Stock Supply through Print Stations

7. Pull the roll of stock to the right of the Stock (web) guides.
8. Feed the web between the two plates that support the registration sensors
9. Continue threading the stock between the print rollers and through the feed.
10. Rotate the black knob on the feed counter-clockwise and advance the stock through the knife and nip rollers and into the stacker (until it extends about ½ inch or 10 mm - 15 mm from the rollers).
11. If the stock will not advance through the knife, refer to Section 5.4.2, Knife Home Position Adjustment.
12. Rotate the stock web guide knob to align it to the stock width.
13. Close the upper and lower print rollers.




Figure 10. Stock Supply Through Knife and Stacker


4.1.4 Butt Splice



CAUTION: To prevent damage to the print head, do not use butt splices.


The SNAP 700 printer is designed to allow for fast, frequent changing and loading of stock and ink. We recommend re-threading the stock rather than to using a butt splice. If you determine that splicing is faster for threading, tape the ends of the stock together. Turn the feed roller and advance the splice through the printer. Do not try and run the splice through the printer as it can cause damage.

4.1.5 Threading Diagrams



Threading Diagram

Note: Decurler &
Web Guide not used
on RFID Set-UP



Threading Diagram - RFID

4.2 Sending a Print Job to the Printer

The print job tells the printer what layout to print, what information to print on the label, and how many labels to print.

Getting a print job to the printer depends on how your company system is set up. You may be using AVERY DENNISON's tag and label design program PCMate Platinum, or you may be using a special application on a PC or a mainframe. Consult your supervisor on how your company sends print jobs.

4.3 Printing Labels

4.3.1 The Control Panel

The Control Panel on your SNAP 700 printer is located at the top of the machine. Figure 11 shows the control buttons and lights displayed on the printer. The buttons allow you to control the printer, and the lights indicate the status of the printer.



Figure 11. Control Panel

- The **Start/Stop Button** is a blue button that starts and stops printing. If there are labels ready to print, pressing the Start/Stop Button starts printing. If the printer is running, pressing the Start/Stop Button stops printing.
- The **Ready Light** is a green light that indicates the printer has been powered up, completed its diagnostics, and is ready to accept print jobs.
- The **Data Light** green light that indicates you have sent a print job to the printer and it is ready to print. If the Data Light is flashing, you are at end of day (see section 3.3.4).
- The **Supply Light** is a yellow light indicates that: either the stock or ink supply has run out and needs reloading or the stacker is full. It may also come on if you have an accessory attached and there is a problem with it.
- The **Error Light** is a red light that indicates a problem exists somewhere in the printer.
- The **Voice Button** is a yellow button and will play a message describing the status of the printer. Use it to determine causes of printer issues. If the printer is printing, pressing the Voice Button will stop printing.

4.3.2 Printing

Sending a print job to the printer causes the Data light to come on. Press the Start/Stop Button to start printing.

When printing starts, the stacker will move the platform to the correct position. Then the printer will start printing labels.

As the printer prints, the cut labels will drop onto the top of the stack. As the stack grows, the stacker platform moves down so that the top of the stack stays in the same position.

4.3.3 Handling the Leader

The printer may generate a “leader”. A leader is a longer piece of stock that may be blank or may have some partially printed labels. Certain errors and actions, such as opening a printhead, cause the printer to lose track of labels it has printed. The printer reprints these labels. Therefore, discard the leader and do not attempt to use the labels.

When the printer creates a leader, grab it as it comes out of the nip rollers and pull it out of the stacker when the printer does the first cut. (If you are not using the stacker, or you are using some other accessory such as a Rewinder, you may need to handle the leader differently.)

4.3.4 Feeding the stock

To feed the stock, press and hold the Start/Stop button. After a short delay, the printer will feed tape through the printer. To stop the feed, release the Start/Stop button. After a certain amount of stock, the knife will cut.



If you are in the middle of printing a batch, feeding the tape will cause the printed labels between the printhead and the knife to feed through without cutting. These labels will be re-printed the next time you start printing. The batch quantity will be correct.

4.3.5 Errors

The printer may encounter a problem during printing. It will stop and turn either the Supply or Error light on. The Supply light indicates a problem with either the ink or the stock, or the stacker is full. The error light indicates a some other problem.

Determine the problem by:

1. Pressing the Voice button. A message will play that describes the problem.
2. Checking the Printer Status box on the Virtual Control Panel in PCMate Platinum. See section 5.3 for a description of the Virtual Control Panel.


Correct the problem and press the Start Button to start printing again.



NOTE: If the error condition no longer exists, the printer will start. It is not necessary to press the Start button twice as is required with previous AVERY DENNISON printer models. If the error continues to recur, contact your local AVERY DENNISON representative.

4.3.6 RFID Printed Errors

RFID errors will show as printed stripes on the label.



Write failed ("locked tag")

Write failed ("no write")

4.3.7 End of Day

The printer has a feature that minimizes the production of leaders between print jobs. When finished all print jobs, the printer stops with a few labels unprinted. The Data Light flashes. Sending another print job allows the printer finish the labels from the previous print job before starting the new job. This way the printer does not produce a leader and minimizes waste of stock and ink.

If all the jobs are finished or a stock and ink change is needed, and the data light is flashing, press the Start/Stop Button. The printer will print the remaining labels of the last print job. Do whatever is necessary. The printer will produce a leader before printing the next job.

4.3.8 Clearing Print Jobs

To clear print jobs, press and hold both the Start/Stop and Voice buttons together. After about 2 seconds, the voice says "Clearing Current Batch." If there is only one print job, the Data light will go out.

To clear just the current print job, release the buttons. To clear all print job, continue to hold the buttons until the voice says, "Clearing All Batches."

4.4 Using Pre-Printed Stock

When using pre-printed or die-cut stock, the printer must detect a sense mark on the stock in order to print in the proper place.

- The SNAP 700 printer comes with a through-hole sensor standard. The sensor, mounted in the Sensor Module, will detect a hole or slot any location across the width of the stock. Adjusted the sensor position to the hole or slot to register.
- The printer also comes with top reflective sensor standard. This sensor, built into the same through-hole sensor, detects a black sense mark printed on the top side of the stock.
- The bottom reflective sensor is also standard on the SNAP 700. This sensor is built into the through-hole sensor and will detect a black sense mark printed on the bottom of white tape or tag stock.
- Two contrast sensors are options. Both are dimensionally identical and use a fiber-optic pickup tube mounted in the up-right frame with the tip protruding into a slot in the left guide shaft. The contrast sensor detects most sense marks. The color/contrast sensor detects colored and more difficult sense marks.
- The fiber-optic pickup tube is moveable and will detect sense marks across the entire width of the supply. Refer to appendix 7 for instructions on teaching these sensors.

4.4.1 Selecting the Sensor

Select the sensor one of two ways. First, the sensor type can be selected as part of the format (see the PCMate Platinum manual or the PCL manual for details). Second, override the format sensor using the Virtual Control Panel. If the Format sensor type is selected, the printer will use the sensor specified in the format. If one of the other sensor types is selected, the printer will use that sensor and ignore the selection in the format.



The printer does not know if the optional sensors are installed. If one of these sensors is selected but not installed, the printer will not operate properly.

4.4.2 Aligning the Stock to the Sensor

In order to work properly, the stock must be aligned to the sensor before starting to print. To do this, close one or both print-head rollers (depending on whether the label is single- or double-sided) and use the Auxiliary Feed knob until the sense mark is just to the left of the sensor. Then rotate the ink rewind arbors to take up any slack and press the Start Button.



This alignment must be done anytime the printer would normally create a leader. This will happen after most errors. Do not align the stock after a normal stop or a stacker full.

4.4.3 Aligning the Sensor to the Stock

The SNAP700 has two sensors that operate together to provide the hole, top reflective, and bottom reflective sensor functions. These sensors are small black rectangular plastic modules that move across the web by turning the adjusting knob. One sensor is above the web and the other is below the web. There are two “dimples” in the sensor body that mark the sense position.

When using a hole sensor mark, align the inboard dimple with the hole in the web. When using either top or bottom reflective sense mark, align the mid-point between the dimples with the printed mark.

If the sensor is not properly aligned when printing is started, the printer will stop with the Supply light flashing. Pressing the Voice button will give an error message that will identify the type of sensor. For example, if the format calls for a hole sense mark (or the front Panel Sensor Override is set to Hole), the message will be “Hole Sensor Calibration Error”. This error will also appear in the Virtual Front Panel.

In this mode, the Supply light will flash at a rate that is proportional to the alignment of the sensor to the sense mark. If the sensor is not aligned with the sensor mark, the light will flash slower. If the sensor is aligned with the sense mark, the light will flash rapidly or stay on.

To align the sensor to the sense mark, move the stock so that the sensor mark shows in the slot under the sensor. Then adjust the sensor across the web until the Supply light flashes rapidly or stays on. For best alignment, move the sensor to the point where the light flashes most rapidly, and then continue to move the sensor in the same direction until the light starts to flash more slowly. Then move the sensor back to a point in between those two points.

Press Start again to begin printing.

4.5 Option Menu System

The Option Menu System allows you to

- Print test labels
- Set the voice volume



When the instructions say to press a button, press the button for a short time and release it. When the instructions say to press and hold a button, press the button and hold it down until the printer responds.

When you are in the Option Menu System, you can get out by pressing and holding the Voice button until the printer says “Returning to print mode.”

Use the Start / Stop and Voice buttons to move through the Option Menu System. Each time you press a key, a voice message will follow, or the machine

will initiate or stop an action. Regardless of which of the three functions you want to select in the Option Menu System, you select it the same way:

1. Press and hold the Voice button for about two seconds.
2. Voice says, "Press Start for Test Pattern."
3. If you do not want to run a test pattern, press the Voice button.
4. Voice says, "Press Start for Demos."
5. If you do not want to listen to the demos, press the Voice button.
6. The voice message will respond with, "Press Start to Set Volume."
7. If you do not want to change the speaker volume, press the Voice button.
8. The printer will say "Returning to Print Mode." At this time the Option Menu System is complete and the printer is back to normal operation.

For more information on how to use each of the three possibilities in the Option Menu System, Running Test Labels; Using Voice Demos; and Setting / Adjusting Voice Button Volume. Appendix 8 contains a flowchart of the Option Menu System.

4.5.1 Running Test Patterns

Your SNAP 700 printer offers you two Test Patterns to run before you proceed to production.

Test Pattern 1 (Narrow Setup Test Pattern), is a format designed to run on a 2" wide fabric. It consists of a solid line down the middle on the front and back of the label and a solid line across the web that is exactly 1" from the cut, along with a 2" wide brick pattern. These lines are helpful in adjusting print position to compensate for mechanical tolerances in the printer, and the brick pattern can be used to detect dot out in the head.

Test Pattern 2 (Wide Setup Test Pattern) is similar to Test Pattern 1, except that it is designed to run on a 5" wide stock.

Test Pattern 3 and 4 (Custom Test Pattern 1 and Custom Test Pattern 2) more closely resemble actual labels and can be used to make adjustments to the printhead pressure and contrast (see section 4.1.1 and 4.1.2).

When you have determined which Test Pattern you wish to operate, use the appropriate procedure.



NOTE: The printer is set up to print the selected label test format in a very large quantity. Manually start and stop the printing to make any necessary adjustments and to end the test run.

Test Pattern 1

1. To run a test label, press and hold the Voice button about two seconds. Voice says, "Press Start for Test Pattern."

2. Press the Start / Stop Button. Voice says, “Press Start for Narrow Setup Test Pattern”.
3. Press the Start / Stop button. Voice says, “Ready to Print Narrow Setup Test Pattern. Returning to Print Mode.” The Data light will turn on.
4. Press the Start / Stop button. The machine will begin printing Test Pattern 1.
5. To stop printing the test labels, press the Start / Stop button. The Data light will remain on. Make any necessary adjustments, and press Start / Stop to resume printing the test labels.
6. Once satisfied with the test label you are running, press either the Start / Stop or Voice button to stop the test run. The Data light will remain on.
7. Press and hold the Start / Stop and Voice buttons together to clear the current print job.
8. Voice says, “Clearing Current Batch.” The Data light will go out.




Figure 12a. Running Test Patterns

Test Pattern 2

1. Press and hold the Voice button for about two seconds. Voice says, “Press Start for Test Pattern.”
2. Press the Start / Stop button. Voice says, “Press Start for Wide Setup Test Pattern”.
3. Press the Voice button. Voice says “Press Start for Wide Setup Test Pattern”.
4. Press the Start / Stop button. Voice says, “Ready to Print Wide Setup

Test Pattern. Returning to Print Mode.” The Data light will turn on.

5. Press the Start / Stop button. The machine will begin printing Test Pattern 2.
6. To stop printing the test labels, press the Start / Stop button. The Data light will remain on. Make any necessary adjustments, and press Start / Stop to resume printing the test labels.
7. Once satisfied with the test label you are running, press either the Start / Stop or Voice button to stop the test run. The Data light will remain on.
8. Press and hold the Start / Stop and Voice buttons simultaneously to clear the current batch of labels being printed.
9. Voice says, “Clearing Current Batch.” The Data light will go out.

Test Pattern 3 and 4

The procedure for printing test pattern 3 and 4 is the same as described above.

4.5.2 Setting / Adjusting Voice Button Volume

The volume level of the voice messages on your SNAP 700 printer is set at Level 3 at the factory. To adjust volume:



NOTE: When you select volume setting, the menu will begin with the current volume at which your machine is set, Level 3.

1. Press and hold the Voice button longer than two seconds to activate the Option Menu System.
2. Voice says, “Press Start for Test Pattern.”
3. Press the Voice button. Voice says, “Press Start for Demos.”
4. Press the Voice button. Voice says, “Press Start to Set Volume.”
5. Press the Start / Stop button. Voice says, “Press Start for Volume Level 3.”

To increase from volume level 3 to 5, follow these additional steps.

6. Press the Voice button. Voice says, “Press Start for Volume Level 4.”
7. Press the Voice button. Voice says, “Press Start for Volume Level 5.”
8. Press the Start button. Voice says, “Volume Set to Level 5. Returning to Print Mode.”



NOTE: Each time you press the Start button, the volume level will increase by one increment until the maximum level is reached.

If you want to decrease the voice volume to Level 1 or 2, follow Steps 1-7 above and continue to press the Voice button until you reach the desired volume level.




Figure 12c. Adjusting Voice Volume

5.0 Making Adjustments

5.1 Print Head Adjustments

The print stations on the SNAP 700 printer are stationary. The print rollers swing open for loading stock and ink and are closed when the machine is printing. The rollers are held in the print position with a latch on both the inside and outside end of the rollers.

When printing labels, there are three adjustments you may need to make to the print stations: (1) adjust the print head pressure, (2) adjust the contrast, which controls print darkness (density), and (3) slide the print head pressure spring toward the front or rear of the machine across the width of the printhead.

5.1.1 Adjusting Print Head Pressure

Each print head has one print head pressure knob, screwed into a slide block (see Figure 13). Change print head pressure settings as follows:



CAUTION: For extended print head life, use the lightest print pressure setting whenever possible.

To increase or decrease print head pressure, turn the pressure adjustment knob. Turn the knob down to increase head pressure and up to decrease pressure. The knob can be backed out of the head bracket if loosened too much. Replace the pressure knob assembly into the threaded hole.



CAUTION: Ensure that both knobs on the print head have about the same spacing from the head mount bracket.




Figure 13. Print Head Components

5.1.2 Adjusting Density (Darkness)

The contrast knob for adjusting print density (darkness) is located on the front of each print station (see Figure 13). You may adjust the contrast knob while printing labels.

The nominal contrast setting is in the center of the rotation.

1. To increase print density, rotate the contrast knob clockwise.
2. To decrease print density, rotate the contrast knob counterclockwise.

You can manually rotate the contrast knob 270 degrees. At maximum value, the print will not become any darker. In fact, it may actually begin to get lighter.



CAUTION: For extended print head life, use the lowest print contrast the produces acceptable print quality.

5.2 Adjusting the Stacker

The stacker on your SNAP 700 printer is adjustable in four ways: the position of the stacker on the mounting pins, the height of the stack, the angle at which labels are accumulated in the stack, and the angle of the platform. Different settings of these adjustments may be needed depending on the length and width of the labels being printed and the material being used. There are no incorrect settings, only adjustments that allow the stacker to better accommodate the size and type of material used for the label being printed and stacked. You will soon learn the settings that work best for your labels.

5.2.1 Stacker Position

The stacker slides in and out on the mounting pins. This allows for proper positioning of the stacker for the width of the label you are printing. The stacker should be set so that the back wall of the stacker is just behind the back end of the label where it comes out of the nip rollers.

The stacker mount bracket has a thumbscrew that locks the stacker in position and also stiffens the mounting.

Adjusting the stacker angle (see section 4.2.3) will move the position of the back wall. If you adjust the stacker angle, be sure to readjust the stacker position.

5.2.2 Toggle Switch

The stacker has two electronic sensors that set where the top of the stack is. Depending on the size of the label to be collected on the stacker, use the toggle switch to select from the two different electronic sensors (See Figure 5 and 11). There is no correct or incorrect switch setting. Use the setting that works best.

1. Determine the size of label to be printed.

- a. For short feeds ranging from 1 - 2 inches (25 mm – 51 mm), use the upper sensor.
- b. For long feed and/or woven labels, use the lower sensor.
2. Depress the top portion of the toggle switch to use the upper sensor.
3. Depress the bottom portion of the toggle switch to use the lower sensor.

5.2.3 Stacker Angle

The angle of the stacker is adjustable, and can be tipped out a maximum of 20 degrees at the bottom from the vertical position shown in Figure 5. Since there is no single stacker angle that is best for all label lengths and types of materials, you can adjust the stacker angle to best accommodate each run.

1. When the feed is 2 inches (51 mm) or longer, or when using coated tapes, the stacker works well with the bottom tipped out.
2. When using woven tapes, the stacker should be vertical or almost vertical.




Figure 14. Stacker Angle – Almost Vertical

5.2.4 Platform

The platform angle can be adjusted in two different locations to alter the angle at which labels are stacked and stopped.

1. Pull the spring loaded Adjustment Pin and move the platform from a horizontal to a backwards angle approximately 20 degrees up on the outer end of the platform.

- a. For satin labels, use the lower position.
- b. For coated labels, and short feed labels, elevate the outer end.

The label stop helps position the labels in the stack. The label stop is magnetic. Follow these steps to adjust the position of the label stop.

2. Place a cut label on the stacker platform and slide it into the back corner.
3. Move the label stop to within 1/8 inch (3 mm) of the end of the label.

5.2.5 Static brush

The static brush has been mounted with a thumbscrew for easy adjustment to help guide and control labels into the stacker. The brush should contact the material as it exits the nip rollers. The static brush should be maintained in good condition for the best stacking.

In general – a light pressure is sufficient to stack well, but long feeds will require slightly more pressure.

Keep the static brush parallel to the nip roller mount bracket.

5.3 Virtual Control Panel

5.3.1 Introduction

PCMate Platinum allows the operator to control the printer and make adjustments directly from the PC.

The **Virtual Control Panel** (VCP) shows at the bottom of the PCMate Platinum screen when a SNAP 700 printer is properly connected (see figure 21).




Figure 21: PCMate Platinum Print Module with Virtual Control Panel

If more than one printer is connected, select the printer of interest from the “Printer Selection Box”

The VCP has controls and lights that simulate the printer's control panel that work the same way. With no Voice Button, messages are displayed in the Printer Status box. Start and stop the printer with the Start/Stop button.

The Printer Status boxes show the Batch ID, quantity, and printer status.

Clear the current batch or all batches using the Batch Control buttons on the right side of the window.

5.3.2 Changing Printer Settings in PCMate

Click on the “Show Settings” button on the VCP to bring up the **Printer Settings** Window.




Figure 22a: Virtual Control Panel with Show Setting Window (Firmware 3.35 and below)




Figure 22b: Virtual Control Panel (Firmware 3.36 and PCMate 7.6 and above) showing the adjustments available across the width of the printer.

Printer settings have several pages. Click on the tab to select one of the pages.

5.3.3 Print/Cut Adjust Tab

The cut adjust will help the printer cut in the right place with relation to the sense mark on pre-printed tape. Cut adjust is found the **Print/Cut Adjust** tab.

Use cut adjust with pre-printed tape only. Put cut adjust to zero when using blank tape and use print adjust to position the print properly on the label relative to the cut.

When the cut adjust is set correctly, the printer will cut the label at the leading edge of the sense mark. If the cut is not in the right place, increase the cut adjust value to move the cut to the right (looking at the printer) or decrease the value to move the cut to the left. Each step is 0.003"/0.076mm.

The print adjust allows you to move the print with relation to the cut, one print adjustment for each print station.

Use the Narrow Test Pattern to set the print adjust. The test pattern has a line printed across the tape that is 1" from the cut. Run a few labels and measure the distance from the cut to the line. Then, increase the print adjustment value to move the print to the right, or decrease the print adjustment value to move the print to the left. Each step is 0.003"/0.076mm. Repeat until the line is in the correct place.

Facing the printer, the inboard side is closest to the printer body, and an operator side is closest to the operator. Use the following guide to understand the numbers.




Figure 22c: Print adjust and width adjust

Image adjust across the width of the printer is available through Firmware 3.36 and above, using PCMate 7.6.2 and above.



NOTE: Don't use print and cut adjusts to "fine-tune" a format. Rather correct any print position problems in the format and use these adjustments to correct printer variation only. Otherwise, you have to adjust each format before printing.


5.3.4 Selecting the Printer Language

The SNAP 700 printer has the capability of presenting both text and voice messages in multiple languages.



The printer is shipped with several languages installed. When performing an upgrade, however, the Operating System (OS) upgrade file contains only the English language messages. A separate language upgrade is required to add any new prompts in other languages.

In the Virtual Control panel, click on the “Options” tab.



To select the printer language, click on the arrow in the Language box to drop down a list of available languages. Click on the desired language. Then click on Apply or Close to activate the selected language.



Selecting the printer language does not change the PCMate Platinum language. See the PCMate Platinum manual for information about changing languages.

5.3.5 Setting the Date and Time

The SNAP 700 printer has a built-in clock and calendar. You may change the date and time as follows:

In the Virtual Control Panel, click on the Options Tab. The current printer date and time is shown. You may change the values in the Date or Time box, or you can simply click on the Sync to PC button to set the printer to the same date and time as the PC. Click on Apply or Close to set the printer date and time.

5.3.6 Enabling or Disabling the Cutter

You may disable the cutter in order to use an accessory such as a Rewinder. If the cutter is enabled, it will cut according to the Cut Count selected in the format. If the cutter is disabled, it will not cut between labels.



The optional Sonic Knife will be also be enabled or disabled using this command.

In the Virtual Control Panel, access the Options Tab. Click on the arrow in the Cutter box. Select Enabled to run the cutter or Disabled to turn the cutter off.

5.3.7 Selecting the Print Speed

The print speed is normally set in the format. You may override the format setting and specify the speed you want the printer to run. This is useful if you have formats that were designed for other AVERY DENNISON printers.

In the Virtual Control Panel, select the Options tab. Click on the arrow in the Print Speed box to drop down a menu of print speed choices. Click on the desired choice and click on Apply or Close to set the print speed.

The available choices are:

- Format – use the print speed specified in the format. If the print speed does not exist in the SNAP 700 printer, it will use the closest print speed that is not greater. For example, if the format was designed for a 676 printer and calls for 5 ips, the SNAP 700 printer will use 4.5 ips.
- Translate – uses the corresponding speed from the printer specified in the format. For example, if the format was designed for a 676 printer and called for 5 ips (the third speed in the printer's speed list of 3, 4, and 5 ips), the SNAP 700 printer would use 6 ips, which is the third speed in its speed list of 3, 4.5, 6, and 7 ips.
- 3, 4.5, 6 or 7 – selects the desired print speed.

5.3.8 Selecting the Flagging Mode

This selection allows you override the flagging mode specified in the format. It is set in the same way as the Print Speed.

The available selections are:

- Format – uses the flagging mode specified in the format
- Side-step – This selection is for the High Volume Stacker, which is not available for the SNAP 700 printer. Do not select this.
- Disabled – Disables flagging. No flagging will be done.

5.3.9 Selecting the Sense Mark Type

This selection allows you to override the sense mark type (none, top reflective or bottom reflective) selected in the format. Its main purpose is to allow you to activate the optional Contrast Sensor, since older formats or formats for other AVERY DENNISON printers will not have the Contrast Sensor type.

This option is set in the same way as Print Speed.

The available selections are:

- Format – use the sense mark type specified in the format
- Top Reflective, Bottom Reflective, Contrast – selects the sensor type
- Disabled – ignores the sense mark. This is useful when designing a format using blank tape to avoid wasting the more expensive pre-printed tape.



The printer does not detect whether the Bottom Reflective or Contrast Sensor is installed. If you select a sensor type that is not installed, the printer will not print properly.

5.3.10 Setting the Default Transfer

The transfer type specifies the type of tape and ink that is being used. For example, transfer type 97 is 4800TWT fabric with CT1111 ink. The transfer type tells the printer how much energy is needed to print when using that tape and ink. See Appendix 2 for a list of available transfer types.

Be sure to specify the transfer type in the format. However, if a transfer type is not specified in the format, the printer uses the default transfer type.




PCMate Platinum always includes the transfer type in the format. If you are using PCMate Platinum, you do not need to specify a default transfer type.

5.3.11 Viewing the Life Counts

The SNAP 700 printer maintains a count of the total number of labels printed, and the total number of inches of material. Also, there is a resettable label counter.

In the Virtual Control Panel, the Life Counts can be found in the Life Counts/Software Version tab. To reset the resettable label counter, click on the Reset button.



5.3.12 Firmware

Check the version of the firmware install by clicking on the Versions/History Tab and noting the Software Version box listed. Use this to verify the firmware version before upgrading.


Printer ID is the printer serial number.

Actual Printhead Resolution is available for version that support 600dpi printing.

5.3.13 Print Quality

If there are problems with the thermal transfer ink wrinkling, you can adjust the tensions of the arbors to remove the wrinkles. Click on the “Arbor Tension Adjust” tab and slide the Unwind and Rewind arbor tensions in order to remove the wrinkles. Too little tension will make more wrinkles. Too much tension will break the ink ribbons.

Tracking issues through the printer can be helped by adjusting the Stock Arbor tension on the right.



5.3.14 Other information on VCP

Print Test Designs – no purpose

Files – lists files stored on the printer. This can help determine in the printer has a font installed.

Diagnostics – Test various printer components by running Interactive SNAP Diagnostics. You can also view the Error Log File.

5.4 Web Server


The SNAP Printer Web Server allows you to:

- setup the networking configurations for the printer,
- view and change the printer settings remotely, and
- upgrade the printer remotely.

See section 3.7 for instructions on connecting a printer to the network.

5.4.1 Viewing and Changing the Printer Settings

Access the web server by opening a new browser window on any computer connected to the network. Enter the printer's IP address in the address bar and press **Enter**. The following window will appear:



The screenshot shows the Avery Dennison SNAP Printer Web Server interface. At the top left is the Avery Dennison logo. The main area is divided into two sections: "Printer Information" and "Status".

Printer Information:


Name:	SNAP
Model:	500
Serial #:	0001817
SW Version:	3.32.05.05 <input type="button" value="Update Firmware"/>
IP Address:	172.18.1.206 <input type="button" value="Network"/>

Status:

Batch ID	NONE
Batch Count	0

Below the printer information is a "Configure" button. Below that is a "Show Files" button.

The values shown are the current printer settings. To change the settings, click the "Configure" button. The following window will appear:



The screenshot shows the CONFIGURATION window. It is divided into four main sections: Counters, Settings, Arbor Tensions, and Print/Cut Adjust.

Counters:

Total Inches:	1761018
Total Labels:	869253
Label Counter:	0

Settings:

Language:	ENGLISH	Choose Language ...
Verifier:	Disabled	Choose Status ...
Cutter:	Enabled	Choose Status ...
Print speed:	Format	Choose Print Speed ...
Flagging:	Format	Choose Flagging ...
Sense Mark Type:	Format	Choose Sense Mark Type ...

Arbor Tensions:

Top Unwind:	+1
Top Rewind:	+1
Bottom Unwind:	+1
Bottom Rewind:	+1
Stock:	0

Print/Cut Adjust:

Top Print Adjust:	-99
Bottom Print Adjust:	0
Cut Adjust:	0
Top Printhead Category:	0
Bottom Printhead Category:	0

At the bottom of the configuration window are buttons for "Reset Counter" and "Apply Changes".

Clicking the "Go Back" button will return to the previous window without making

any changes.

To change any setting, enter the value in the box or select a value from the drop down list. Click on Apply Changes to change the printer settings. Values that are grayed out are not changeable.

5.4.2 Converting the DHCP Address to a Static Address

Once you know the DHCP address, open a browser (Internet Explorer, Firefox, etc.) on any computer connected to the network. In the address bar, enter the DHCP address and press “Enter”. The following window will appear:

Printer Information		Status
Name:	SNAP	Batch ID
Model:	500	NONE
Serial #:	0001817	Batch Count
SW Version:	3.32.05.05	0
IP Address:	172.18.1.206	

Configure			
Counters	Settings	Arbor Tensions	Print/Cut Adjust
Total Inches: 1761018	Language: ENGLISH	Top Unwind: +1	Top Print Adjust: -99
Total Labels: 869253	Verifier: Disabled	Top Rewind: +1	Bottom Print Adjust: 0
Label Counter: 0	Cutter: Enabled	Bottom Unwind: +1	Cut Adjust: 0
	Print speed: Format	Bottom Rewind: +1	Top Printhead Category: 0
	Flagging: Format	Stock: 0	Bottom Printhead Category: 0
	Sense Mark Type: Format		

Show Files

Click on the “Network” button. The following window will appear.

The DHCP address is shown in the IP Address box and the mode is DHCP.

Enter the static IP address in the IP Address box and click the “Submit as Static address” button.

At this time, the IP address is set to the static address and the web server will no longer be available. Enter the new IP address in a new browser window.

Printer Information	
Name:	SNAP
Model:	7000346
Serial #:	7000346
SW Version:	3.28.10.01

Network Configuration	
IP Address:	172.18.1.42
MASK Address:	255.255.255.0
GATEWAY Address:	0.0.0.0
SMTP Address:	0.0.0.0

Reset to DHCP address Submit as Static address

Go Back

5.4.3 Resetting the Printer to DHCP Mode

Before moving the printer to a new network, set up the printer for automatic connection to the new network. Put the printer into DHCP:

- Access the web browser as described above
- Click the Network button. The window shown above will appear.
- Click the Reset to DHCP Address button.

5.4.4 Troubleshooting the Network Connection

1. Turn the printer off and connect a standard computer monitor and keyboard to connections on the printer's motherboard.
2. Turn the printer on. When the prompt "Press F1 to enter setup" appears, press the <F1> key on the keyboard. You have about a second to do this.
3. A window will appear asking for a password. Type IP and press the <Enter> key.
4. A list of commands will appear. Refresh the list by entering a ? (question mark).
5. Make sure TCPIP is enabled. Type "TCPIP" <Enter> If TCPIP is disabled, enter "TCPIP ENABLE" <Enter>.
6. Enter "IP" and the address e.g. "IP 198.1.63.123" <Enter>.
7. Type "Exit" <Enter>. Wait for the printer to complete its initialization.
8. From a PC on the network, start a Command Prompt window by clicking Start – Run and entering "cmd" in the box, then click the OK button.
9. Ping the printer to test it. At the command prompt enter "ping" followed by the IP address e.g. "ping 198.1.63.123" <Enter>.
10. The ping command will try to contact the printer four times. If there is a problem with the connection, the result will be "Request timed out"
11. A successful ping looks like this

```

C:\WINDOWS\system32\cmd.exe
C:\>
C:\>
C:\>
C:\>
C:\>
C:\>
C:\>
C:\>
C:\>
C:\>
C:\>ping 172.18.1.193
Pinging 172.18.1.193 with 32 bytes of data:
Request timed out.
Request timed out.
Request timed out.
Request timed out.
Ping statistics for 172.18.1.193:
    Packets: Sent = 4, Received = 0, Lost = 4 (100% loss),
C:\>

```

```

C:\WINDOWS\system32\cmd.exe
C:\>
C:\>
C:\>
C:\>
C:\>
C:\>
C:\>
C:\>
C:\>
C:\>ping 172.18.1.193
Pinging 172.18.1.193 with 32 bytes of data:
Reply from 172.18.1.193: bytes=32 time<ins> TTL=60
Reply from 172.18.1.193: bytes=32 time<ins> TTL=60
Reply from 172.18.1.193: bytes=32 time<ins> TTL=60
Reply from 172.18.1.193: bytes=32 time<ins> TTL=60
Ping statistics for 172.18.1.193:
    Packets: Sent = 4, Received = 4, Lost = 0 (0% loss),
    Approximate round trip times in milli-seconds:
        Minimum = 0ms, Maximum = 0ms, Average = 0ms
C:\>

```

6.0 Maintenance



⚠ WARNING

Moving parts can crush and cut.

Covers must be in place when energized.

This unit is to be serviced by trained personnel only.

There are hazardous moving parts in the printer. Covers must be in place when energized. Service should be performed only by trained service personnel.

6.1 Print Head Cleaning and Handling



CAUTION: Turn off the power to the printer before cleaning or replacing the print head.



NOTE: AVERY DENNISON recommends cleaning print heads.

1. With alcohol and a cotton pad or cloth every 2-4 hours of continuous usage;
2. With alcohol and Velcro cleaning pads after 8 hours of use.

Print heads are extremely sensitive and can be easily damaged, if not cleaned regularly and handled properly. To help prolong print head life and ensure excellent print quality, AVERY DENNISON recommends the following cleaning schedule.

- After two to four hours of continuous usage, wipe the print heads with alcohol and a cotton pad or cloth.
- After eight hours of continuous operation, a more vigorous cleaning is required. Use alcohol and a Velcro cleaning pad, such as those supplied with each new printhead.

6.1.1 Handling Techniques

Static discharge can easily damage thermal print heads. To avoid a static discharge, follow these procedures.

1. Keep all print heads in their original anti-static bags until they are ready to be installed in the printer.
2. Wear an anti-static wrist strap to prevent static discharge from your body into the printer, when working with a print head. Wear anti-static gloves at all times when handling print heads to prevent oils on your hands from contaminating the print head. The SNAP 700 printer optional spare parts kit

contains an anti-static wrist strap and gloves.

- a. If your company has not purchased the spare parts kit, buy the anti-static wrist strap at your local electronics store.
 - b. Extra anti-static gloves can be ordered from AVERY DENNISON.
 - c. If an anti-static glove is not available, thoroughly wash and dry your hands before handling the print head.
3. Do not touch any terminals extending from the print head or the print line.



CAUTION: Never remove the print head from the printer except to replace it.

Follow AVERY DENNISON's cleaning supply recommendations:

1. Always use clean supplies.
2. Use alcohol and the loop side of a Velcro pad or a cotton pad to clean the print head.
3. Never use anything abrasive to the print head.
4. Never use anything metallic on or near the print head.

6.1.2 Cleaning Procedures



Note: AVERY DENNISON recommends Master Cleaning Kit #921341K for use in cleaning print heads.

1. Before cleaning, turn the printer off. Wear the anti-static wrist strap and be sure the button on the strap makes direct skin contact.
2. Fasten the clip end of the anti-static wrist strap to a metal portion of the printer, usually the stacker.
3. Wear anti-static gloves at all times when handling a print head to prevent skin oils from contaminating the print head.
4. After 2 to 4 hours of continuous use, apply a liberal amount of alcohol to a cotton pad and rub firmly across the print line of the print head several times. Allow the alcohol to evaporate and resume printing.
5. After 8 hours of use, apply a liberal amount of alcohol to the loop side of a Velcro pad and rub firmly across the print line several times. Wait a few minutes for the alcohol to evaporate and resume printing.
6. Clean the print rollers and auxiliary feed rollers with alcohol and a cotton pad.
7. Clean sensors with a dry cotton or foam swab.



CAUTION: Do not use alcohol to clean sensors.

6.2 Print Head Replacement

When you see voids in the printing, and print quality does not improve, even after cleaning the heads, use the following procedure to replace the print heads:

1. Turn off the power to the printer.
2. Remove the stock and ink from the printer for easier print head removal.



WARNING: Before replacing a print head, review the **Print Head Handling Procedure Sheet** packaged with each print head to determine if any procedures have changed.

3. Wear anti-static gloves at all times when handling a print head to prevent skin oils from contaminating the print head.
4. Before installing the printhead, note of the printhead resistance value written on the end of the printhead.
5. Fasten the clip end of the anti-static wrist strap to a metal portion of the printer (usually the stacker) to prevent static from your skin from entering the print station.




Figure 16. Print Head Components

6. Put on your anti-static gloves before beginning to remove the head from the printer.
7. To remove the head lift slightly on the outer end of the head to lift it off the locating pins. Pull the head towards the stacker end of the printer. It will slip out from under the flat retaining springs located at both ends of the head.
8. Unplug the two cables that connect to the print head by grasping the print head cable, rocking it gently (see Fig. 17a). Remove the print head assembly from the print station (see Fig. 17b).



Figure 17a. Unplugging Cable



Figure 17b. Release from springs



Figure 17c. Print Head Removed




Figure 17d. Inserting Print Head

9. Insert the new print head into the print station (see Fig. 17c and 17d).
10. Reconnect the two print head cable connectors, making sure that the connectors are seated tightly.
11. Slide the head mounting plate under the two flat retaining springs until it clicks into position.



WARNING: If the cables are not connected correctly, the print head could be destroyed when the power to the printer is turned on. Check to see that the cable is tight by observing from underneath the print head. The cable's connectors should be inside of the connectors located on the print head.

12. Replace the stock and ink supplies.
13. Turn on the printer.
14. Set the printhead resistance to find the “category” to adjust for variations in the individual printheads. Using the average resistance value from step 4 above, determine the printhead category from the table below

Head Category	Average Resistance
1	1075 - 1122
2	1123 - 1170
3	1171 - 1217
4	1218 - 1265
5	1266 - 1312
6	1313 - 1359
7	1360 - 1407
8	1408 - 1455

15. Set the head category using the Virtual Control Panel in PCMate Platinum.
16. Using the VCP, select the printer's COM port and then the Show Settings button. Click the Options tab and set appropriate head category. Click the Apply Settings button to return to PCMate Platinum.
17. As a final test, make a test run to check the print quality of the labels.

6.3 Lubrication

The SNAP 700 printer is manufactured with ball bearings that do not require lubrication. There are two (2) oil-impregnated bronze bushings in the Nip Roller assembly that do require lubrication.



Caution: AVERY DENNISON recommends lubricating the bronze bushings with one drop of multi-use oil once every month during normal operation.

6.4 Rotary Knife Assembly

The rotary knife assembly for the SNAP 700 printer is fastened directly to the frame. It has been designed to deliver an average of two million cuts if used with woven tapes and four million cuts when used with coated tapes, provided no foreign objects are inserted into the assembly that could damage the knife blades.

Two oil cups on the knife assembly require lubricating. The stationary and rotary blades are field replaceable components. The pressure springs and knife blades should all be replaced at the same time. This will prevent premature failures.



Caution: AVERY DENNISON recommends lubricating the knife oil cups with 2 -3 drop of SAE 30 weight oil once every week during normal operation.

6.4.1 Removing and Replacing the Knife Assembly



WARNING: When adjusting, removing, or replacing the knife assembly, you must turn off the power to the printer to avoid personal injury.

1. Turn off the power to the printer.
2. Using the Feed Roller knob, back the stock out of the knife.
3. Loosen the Retaining Thumb Screw under the outboard end of the knife assembly. It is not necessary to remove the screw to remove the knife assembly
4. Using a 3/16" Allen key or hex "T" handle key, remove the two mount screws that retain the knife to the upright frame (see Fig. 18a).
5. Slide the knife straight out until the rotary knife is out of the motor drive coupler then lift the knife vertically avoiding damaging the stripper fingers. Lift the knife assembly vertically from the printer.




Figure 18a. Outboard End View of Knife


Figure 18b. Removing Knife Assembly



WARNING: Keep your fingers out of the knife assembly to avoid personal injury.

6. Remove the knife oiler/finger guard assembly by removing the two button head screws using a 3/32" allen key. Remove the static brush mounted under the oiler/finger guard assembly. Set them aside to be reused.


7. Remove the three flat head screws that hold the outboard retaining cap using a 3/32" allen key. Do not change the setting of the shear adjustment. Remove the end cap and used blades by sliding the end cap out of the "U" shaped holder. Note the location of the pressure spring to reassemble the knife. The Gold color spring is on the inboard end and the Light Blue spring is on the outboard end of the assembly.
8. Remove the Bridge Blade, Knife Output from the Stationary Knife by removing the two 8-32 x 1/4 BHCS.



9. Re-Install this Bridge Blade onto the new Stationary Knife.
10. Properly dispose of the used knife blades.



Caution: Do not mix new and used knife blades as they will cause premature wear and shorten their life. A chip or a nick in the blades may damage a new blade on start up.




11. Insert the rotary knife blade with the long end and flat to the inboard side of the printer.
12. Place the Gold torsion springs on the inboard end of the stationary knife. The “L” bent tang of the spring will extend towards the back of the knife. The cutting edge of the blade will be to the left of the rotary knife pointing down.
13. Insert the “L” tang of the spring in the back frame before inserting the pivot post into the bushing. The cutting edge of the stationary blade will rest on the smooth cam of the rotary knife.
14. Place the light blue spring on the outboard end of the stationary knife with the “L” tang of the spring extending outboard.
15. Engage the outboard end of the rotary knife into the bearing of the outboard support. Rotate the “L” tang of spring past the end of the rotary knife and engage the pivot stud of the stationary knife into its mounting hole in the shear adjustment block. Pivot the pressure spring “L” tang into its mount hole as the end cap is being moved into its home position.
16. Replace the outboard support cap with the three flat head screws.
17. Replace the oiler/finger guard and static brush. Do not over tighten the two mount screws. Check that the static brush is located properly under the oiler.
18. To insert the knife assembly, slide it down vertically into the space between the Auxiliary Feed and the Nip Rollers. Caution not to bend the stripper finger extending from the feed assembly.
19. Hold the knife assembly on the upper outboard corner. Use a flat blade screwdriver to rotate the rotary knife blade with the screw slot in the knife until the knife blade slips into the drive shaft.
20. Continue to hold the knife assembly in place. Use a 3/16” hex key replace the two mount screws and tighten the outboard thumbscrew.
21. Turn on the power to the printer and allow the knife to return to home position.
22. Rethread the stock through the Auxiliary Feed, Nip Roller, and knife.

6.4.2 Adjust the Knife Home Position

To adjust the Knife Home Position, follow the procedure listed below.

1. Insert a flat blade screwdriver into the slot in the end of the knife.
2. Rotate the screwdriver counterclockwise until you hear an audible click.
3. Continue to turn the screwdriver approximately 1/8 of a rotation more.



6.5 Rubber Roller Replacement

As part of Preventative maintenance, the following rubber rollers must be replaced after 5 million inches of stock has run through the machine or (6) months have passed since the last replacement...whichever occurs first.

1. **05624097** – Assembly, Feed Roller
2. **05625014** – Roller, Molded Platen, Red
3. **05624024** – Roller, Nip Drive, Molded

Failure to replace these rollers as suggested above may result in poor print quality, tracking and feed issues.

7.0 Service Adjustments



7.1 Stock (Web) Guide Position

The stock (web) guide is set at the factory to center the stock to the printed image. If a slight mechanical adjustment is needed, follow these steps.

1. Locate the two plastic thumb screws under the Stock (Web) Guide mount shaft.
2. Loosen the two screws.
3. Slide the guide in and out to the position desired.
4. Re-tighten the two screws.

7.2 Stock (Web) Guide Width Adjustments

Use the knob to move the guides until they touch the edges of the stock. Do not pinch the web as it can damage the edges of tag stock and cause registration errors.

7.3 Stock Feed

The Stock Feed is the assembly located in front of the knife. It requires no pressure adjustment and will move the stock through the printer with one or both heads closed.

The large slotted screws are not for pressure adjustment. They are used to retain the pressure springs. They should be snug to the bottom of their travel to ensure even pressure. If there is a tracking problem and adding back tension to the unwind through the Virtual Control Panel will not correct the tracking problem, loosen only one to correct the tracking is acceptable. The other screw should remain tight to keep the feed from slipping.

If the stock will not advance through the Knife, check to be sure the knife is in the home position (see Sect. 5.4.2, Knife Home Position Adjustment).

7.4 Knife Shear Adjustment



WARNING: Knife adjustments procedure must be followed exactly or damage will occur.

WARNING: When adjusting, removing, or replacing the knife assembly, you must turn off the power to the printer to avoid personal injury.

1. Turn off the power to the printer.
2. Remove the knife assembly from the printer as described in Section 5.4.1. Refer to Figures 19a and 19b.
3. Loosen the outer pivot screw by making one complete turn (see Fig. 19a).
4. The two setscrews move the stationary outboard end of the knife to increase or decrease the shear.
5. To increase the shear, loosen the right setscrew $\frac{1}{4}$ turn (see Fig. 19b) and tighten the left setscrew (see Fig. 19c).




Figure 19a. Loosening Outer Pivot Screw




Figure 19b. Adjusting Right Set Screw




Figure 19c. Adjusting Left Set Screw




Figure 19d. Manual Rotation of Knife Shaft

6. Re-tighten the outer pivot screw. Screw should be snug but not over

tightened. Over tightening may prevent the upper blade from rotating.

7. Rotate the shaft by hand, using the inboard shaft extending from the assembly (Fig. 19d). The knife should rotate freely, and will make a metallic shearing sound during rotation.
8. Insert a strip of the material to be cut so it extends from both sides of the knife. Test by rotating the knife shaft again to cut the material.
9. If the two parts of the material are still attached by thread, the knife is damaged and must be replaced.
10. If your test only cuts the material part way through, an additional adjustment is required.
11. Retest and repeat Steps 9 and 10 above.

8.0 Upgrading the Printer Firmware

8.1 Introduction

The SNAP 700 printer firmware can be updated electronically using “UPG” files received from Avery Dennison. A “UPG” file is a software file with “.upg” as an extension. Files are either “zip” files, which must be extracted/unzipped, or UPG files.

To upgrade the printer firmware, you will need a “UPG” file.

After receiving the “UPG” file, you may upgrade your printer one of three methods way:

- PCMate Platinum can perform the upgrade. This takes approximately 15-20 minutes. Please be patient.
- USB flash drive containing UPG file inserted into one of the USB slots on the back of the printer can perform the upgrade. This takes approximately 4-5 minutes.
- The Ethernet Interface Option if installed can be used to upgrade through the printer's web server.

8.2 Selecting the UPG file

The UPG file you need will depend on the motherboard in the SNAP printer being upgraded. If you are unsure, you can remove the back cover and see the electronic board installed in the bottom of the printer that is horizontal.

Please see the information posted on the support website:

<http://myrbis.averydennison.com/support/firmware-apparel.html>

Download and review the firmware upgrade procedure.

As of Jan 2017, the most recent firmware is 3.36. This supports the latest 3 motherboards for the SNAP (ASUS, Advantech and BCM).

8.3 Getting the UPG file

8.3.1 Getting UPG file using D2Comm

The easiest way to get the UPG file is through D2Comm. If you have a D2Comm account,

- request your D2Comm Coordinator to schedule an upgrade for your account.

- Log in to D2Comm, select “**In Plant**”, and then “**Retrieve Updates**”.
- The upgrade file will automatically download.
- Start **PCMate** to upgrade. There is no need to unzip this file as it will already be a UPG file.

8.3.2 Getting UPG file without using D2Comm

You may download the upgrade file as follows:

1. Go to www.monarch.averydennison.com.
2. On the left, click “**SUPPORT**”, then “**Printer Utilities, Firmware & Drivers**”
3. Next in the Firmware second (2nd one down), click “**Apparel Models – SNAP 500 & SNAP 700**”
4. Choose one of 3 upgrade files. For example, for version 3.36.15.10:
 - a. V3_36_15_10.upg – This is the complete upgrade and includes English and all alternate language messages and prompts
 - b. V3_36_10_10_OS.upg – This is the upgrade with English only
 - c. V_ALT_LANGUAGES.upg – This upgrade contains only the alternate language messages and prompts. This version does NOT contain the printer operating system.




The file that downloads has “zip” extension. You must unzip and extract the UPG file from this download.


8.4 Performing the Upgrade

8.4.1 Unzipping the file

1. Once you have received the upgrade file through D2Comm or the website, make sure it has the “.upg” extension or is an UPG file “Type”. If it has the “.zip” extension, then **unzip/extract** the file to the desired folder.



With extensions




Without extensions


2. If you have a “.zip” file or the “Type” is “Compressed (zipped) Folder”, and then extract/unzip the file by right-clicking on it and selecting “**Extract All...**”. Some version of Windows will allow you to double click on the zip file and copy the internal .upg file to another folder.

8.4.2 Upgrading through PCMate

1. Once you have received the upgrade file through D2Comm, check that the UPG file is in the “C:\D2Comm\Control\” folder.
2. Start **PCMate Platinum**. The following screen will appear.



3. Click on the **Yes** button to start the upgrade. Clicking on the **No** button start PCMate **Platinum**. Each time you start **PCMate Platinum**, this screen will appear until you either perform the upgrade or remove it (see below).
4. When you click on the **Yes** button, the following screen will appear.




If you have more than one printer connected to the PC, they will all show in this window. If you leave the Upgrade Schedule box at Upgrade Now (see below), all the printers will be upgraded, one at a time.

5. In the box under Upgrade Schedule, it will say Upgrade Now. If you click on the box, a drop down list will offer the following choices:
 - Upgrade Now – this will cause the printer to be upgraded when you click on the Start Upgrade button.
 - Upgrade Later – This choice will skip the upgrade for that printer, but keep the upgrade file. The next time you start PCMate Platinum, the upgrade will be offered again. This allows you to skip the upgrade until later.
 - Remove Upgrade – If you select this option, the printer will not be upgraded, and the upgrade file will be deleted.
6. To start the upgrade, click on the **Start Upgrade** button. No further action is required until the upgrade process finishes.

The upgrade process can take quite a while. If the process is interrupted, the printer will attempt to revert to the last revision. If it fails, it will revert to a safe version. If this occurs, it will be necessary to redo the upgrade.


7. The following window will appear.



The following description of the upgrade process is accurate as of this writing. However, changes may be made to improve the process. It is important to allow the process to finish.

During the first part of the upgrade process, PCMate Platinum sends the necessary files to the printer. This screen allows you to monitor the progress of the file transfer. The top progress bar shows the file being sent, while the bottom bar shows the overall progress.


8. Once the files are on the printer, the following window will appear. Do not click on any buttons until the upgrade finishes.



9. The printer will reboot, ring the chimes, and may say,

- Upgrade in progress. Please wait
- Programming MCB. Please wait
- Updating auxiliary files
- Starting system backup of this upgrade
- Distributing language sound files
- Upgrade complete

Then the following window will appear. Click “Close” to continue.



8.4.3 Upgrading through USB Flash Drive

1. Make sure the file you received has a “.upg” extension. If it has a “.zip” extension, then **extract/unzip** to get the upgrade file.
2. Place the upgrade file in the root directory of a USB flash drive.
3. Insert the drive in one of the USB slots on the back of the printer.
4. When the printer is turned on, it will detect the USB flash drive and upgrade the printer automatically.
5. This process takes approximately 4-5 minutes.

Some older operating systems do not support this function. If you try it and it doesn't work, you must upgrade using PCMate.

8.4.4 Upgrading through the Webserver

This instruction uses the Filezilla FTP Client Application as an example. Filezilla is an open source FTP client that is available freely from <http://filezilla-project.org/>. Other FTP clients operate in a similar manner.


This upgrade procedure is only available in printer firmware version 3.28.11.01 and above. If the printer is not at this version or above it must be upgraded through PCMate or a USB drive. Future upgrades can then be done through the Web Server.

Make sure your file has the “.upg” extension or the file type is “UPG file”. If it has the “.zip”, you must extract/unzip the file before using.

Accessing the printer through Filezilla or another ftp client allows access to the entire printer file structure. Moving, deleting or otherwise changing any files or folders can result in erroneous operation or disabling of the printer. Use caution.

Connecting to the Printer through Filezilla


1. Start the Filezilla application. The following window will appear:



2. Enter the printer's IP address in the host box, enter the printer's username (Avery) and password (Dennison) in the corresponding boxes, and click the **Quickconnect** button.
3. The screen is divided into two sets of panes. The left panes show folders on the computer, and the right panes show folders on the printer. The top pane on each

side shows the folder, and the bottom pane shows files and subfolders in the highlighted folder.

4. The information in these panes is not live – it is a snapshot of the file structure when the screen was last refreshed. To refresh the screen, select View – Refresh from the menu or click the Refresh icon on the toolbar. Transferring the Upgrade File to the Printer
5. The screen below shows Filezilla ready to transfer the upgrade file to the printer. In the left panes, the folder on the computer that hold the upgrade file has been selected in the upper pane and the upgrade file is selected in the lower pane. In the right panes, the root directory of the printer is shown. The upgrade file must be placed in the printer's root directory.



6. To transfer the file, simply drag it from the bottom left pane to the bottom right pane, or double click the upgrade file.

There may be a folder in the root directory of the printer called PAXA. This is a temporary folder used in processing the upgrade file. Ignore this directory and place the upgrade file in the root directory.

7. To upgrade the printer, first open a browser window, enter the printer's IP address in the address bar, and press **Enter**. The following window will appear.



AVERY DENNISON®

Printer Information		Status
Name:	SNAP	Batch ID
Model:	500	NONE
Serial #:	0001817	Batch Count
SW Version:	3.32.05.05 Update Firmware	0
IP Address:	172.18.1.206 Network	

[Configure](#)

Counters	Settings	Arbor Tensions	Print/Cut Adjust
Total Inches: 1761018	Language: ENGLISH	Top Unwind: +1	Top Print Adjust: -99
Total Labels: 869253	Verifier: Disabled	Top Rewind: +1	Bottom Print Adjust: 0
Label Counter: 0	Cutter: Enabled	Bottom Unwind: +1	Cut Adjust: 0
	Print speed: Format	Bottom Rewind: +1	Top Printhead Category: 0
	Flagging: Format	Stock: 0	Bottom Printhead Category: 0
	Sense Mark Type: Format		

[Show Files](#)

8. Click the **Upgrade Firmware** button. The printer will perform the upgrade operation automatically.
9. There is no indication from the browser when the upgrade is complete. To determine if the upgrade is complete, refresh the browser window. When the upgrade is complete, the above window will reappear with the new firmware version shown in the SW Version box.

If you refresh the browser window during the upgrade process, you will receive an error message that the connection has timed out or the web page is unavailable. Simply refresh again until the web page appears.

9.0 Electrical Troubleshooting

9.1 Power Up / Sign On / Communications

Problem	Probable Cause	Corrective Action
LEDs do not light.	1) Incorrect supply voltage.	1) Confirm that the AC entry is configured for the line voltage intended to be applied to the machine. Failure to do so can damage the machine's internal power supply. Refer to Appendix 1, "Fuse Configuration."
	2) Machine is not plugged in.	1) Check that both ends of the power cord are plugged in securely. 2) Confirm that the outlet the machine is plugged into has power.
	3) Missing or blown fuse(s).	1) Check that the fuse(s) located inside the AC entry are present and intact. Replace as needed. Refer to Appendix 1, "Fuse Configuration."
LEDs flash	1) PC board power failure	1) Cycle the power off and back on again.
Printer says "Boot Error 1" or "Hardware error 1, printer requires service" or "PCI interface bad change MCB". During the power up of the printer.	1) PCB failure	1) Replace MCB board
	2) Motherboard failure	1) Replace motherboard
Printer says "Boot Error 2" or "Hardware error 2, printer requires service" or "BIOS corrupted, replace the mother board" or "Reset the BIOS". During the power up of the printer.	1) Corrupted BIOS	1) Connect a standard PC monitor and keyboard to the printer and follow the instructions found in the Engineering Bulletin "06_015_500_BIOS_Revised.doc" to reset the BIOS settings.
	2) Motherboard failure	1) Replace motherboard
Printer says "Boot Error 3" or "Hardware error three" during power up. Printer requires service. Corrupted safe operating system. Replace the flash disk". (Message depends on software version.)	1) Flash Disk Failure	1) Replace Flash Disk Module
	2) Motherboard Failure	1) Replace motherboard

Printer says "Boot Error 4" or "Hardware error 4. Printer requires service" or "Cannot communicate with the MCB. Change the MCB" during power up. (Message depends on software version.)	1) PCB failure	1) Replace MCB Board
	2) Motherboard Failure	1) Replace motherboard
Printer says "Running Backup Operating System. Please upgrade" after power up. (Message depends on software version.)	1) Upgrade failure	1) Upgrade to the latest operating system.
Printer says "Running Safe Operating System. Please upgrade" after power up. (Message depends on software version.)	1) Software failure	1) Upgrade to the latest operating system. NOTE: The safe operating system will run the printer, but it does not have the latest features and improvements. Upgrade as soon as possible.
Machine does not receive data.	1) Communications cable is loose or unconnected.	1) Check and secure both ends of the serial cable with the thumbscrews.
	2) Incompatible communication cable	1) Ensure the communication cable is a null modem serial cable with DB9F connector.
	3) Machine is not powered on or has not completed diagnostics tests.	1) Power machine on and wait until machine ready light is on. Re-download data.
	4) Data sent to wrong printer.	1) In PCMate Platinum change to the printer where the data is intended to be sent.
	5) Configuration incorrect in PCMate Platinum .	1) Reconfigure PCMate Platinum for AVERY DENNISON PCL printer as per your PCMate Platinum manual.
	6) Faulty Mother Board	1) Replace the Mother Board.



IF THE RECOMMENDED CORRECTIVE ACTIONS DO NOT RESOLVE THE PROBLEM (S), CONTACT YOUR LOCAL AVERY DENNISON REPRESENTATIVE.

9.2 Stock / Ink Advance

Problem	Probable Cause	Corrective Action
Stock or ink does not advance when the start button is depressed.	1) No batches to be printed. (Data light is not on.)	1) Download batch (If batch downloaded uses the same design as a previously downloaded batch, the machine will start automatically).
	2) An interlock condition exists. (Supply or Error light is on.)	1) Press the voice button to determine the error. 2) If using PCMate Platinum, check the virtual control / display.
	3) Stock is bound.	1) Remove and rethread the stock.
	4) Ink is bound.	1) Remove and rethread the ink.



IF THE RECOMMENDED CORRECTIVE ACTIONS DO NOT RESOLVE THE PROBLEM (S), CONTACT YOUR LOCAL AVERY DENNISON REPRESENTATIVE.

9.3 Print

Problem	Probable Cause	Corrective Action
Stock advances but the printer does not print.	1) Stock registration sensor is misaligned (preprinted stocks only).	1) Re-align sense mark with sensor, refer to section 3.3.6.2 Sensors.
	2) Print head cable is disconnected or faulty.	1) Power off the machine and reinsert the print head connector or replace the cable.
	3) Print head is faulty.	1) Replace the print head.
	4) Stock and Ink Transfer Type selection in Design File doesn't match supplies.	1) Refer to the PCMate Platinum software manual.
Machine stops after every third label.	1) Stock registration sensor is misaligned (preprinted stocks only).	1) Refer to the PCMate Platinum software manual.
	2) Label length selection in the Design File doesn't match the printed stock length.	
Print registration is off in the feed direction.	1) Print position is incorrect.	1) Use the Virtual Control / Display or adjust the print position.
	2) Field(s) position incorrect in the Design File.	1) Refer to PCMate Platinum software manual.
	3) Sense-to-cut selection in the Design File is incorrect.	1) Refer to PCMate Platinum software manual.
	4) Bound print roller.	1) Check that the print roller turns freely on its shaft. If it does not, replace it.
Print registration is off in the web direction.	1) Machine is incorrectly threaded.	1) Check and rethread the media as needed. Refer to section 3.1.3 Loading the Stock.
	2) Web guides incorrectly adjusted.	1) Check and adjust web guides as needed. Refer to section 6.2, Stock (Web) Guide Width Adjustments.
	3) Stock Arbor is not tight.	1) Check and adjust as needed. Refer to section 3.1 Loading Supplies.



IF THE RECOMMENDED CORRECTIVE ACTIONS DO NOT RESOLVE THE PROBLEM (S), CONTACT YOUR LOCAL AVERY DENNISON REPRESENTATIVE.

Problem	Probable Cause	Corrective Action
Print density is too light or too dark.	1) Stock and Ink Transfer Type selection in Design File doesn't match supplies.	1) Refer to the PCMate Platinum software manual.
	2) Incorrect contrast setting in the machine setup.	1) Adjust the contrast control on each print head. Refer to section 4.1 Print Head Adjustments.
	3) Misadjusted print head pressure.	1) Set print head pressure. Refer to section 4.1 Print Head Adjustments.

Problem	Probable Cause	Corrective Action
Voids in print image in the feed direction.	1) Ink is misaligned with the stock.	2) Ink must be 1/4" or 5 mm wider than the stock. Example: 1"(25 mm) web requires 1 1/4" (30 mm) ink.
	2) Print head is dirty.	1) Power off the machine. Clean the print head and print. Refer to section 5.1, Print Head Cleaning and Handling.
	3) Faulty print head.	1) After cleaning the print head and running a test label, if a void still exists, replace the print head.
	4) Misadjusted print head pressure.	1) Set print head pressure. Refer to section 4.1.1, Adjusting Print Head Pressure.
	5) Worn printer roller.	1) Contact your local AVERY DENNISON representative.



IF THE RECOMMENDED CORRECTIVE ACTIONS DO NOT RESOLVE THE PROBLEM (S), CONTACT YOUR LOCAL AVERY DENNISON REPRESENTATIVE.

9.4 Cut / Stack

Problem	Probable Cause	Corrective Action
Machine fails to cut labels (the rotary knife does not rotate).	1) The knife is disabled.	1) Enable the knife in the setup menu via the Virtual Control / Display in PCMate Platinum section 8.0.
	2) Cut count is set to "0" in the Design File.	1) Refer to the PCMate Platinum software manual.
The stacker platform fails to run.	1) The stacker cable is disconnected.	1) Power off the machine and insert the stacker cable in the stacker port.
Labels will not stack.	1) Stacker is not operating.	1) Be sure the nip roller is free to rotate.
	2) Stacker position on the machine too high or too low.	1) Move the toggle switch to the opposite position.
	3) Incorrect position platform bed angle.	1) Use the pull pin to change the platform angle.
Knife does not cut completely through.	1) Knife blade shear is misaligned.	1) Refer to section 6.4, Knife Shear Adjustment.
Knife will not cut.	1) Knife blades are dull.	1) Refer to section 5.4.1, Removing and Replacing the Knife assembly.



IF THE RECOMMENDED CORRECTIVE ACTIONS DO NOT RESOLVE THE PROBLEM (S), CONTACT YOUR LOCAL AVERY DENNISON REPRESENTATIVE.

9.5 Printer Errors

Printer errors are indicated by either the Supply or Error light being on.

When the Supply light is on, the printer supplies (stock or ink) require attention. Generally, this means the stock or one of the ink rolls is empty, or the stacker is full.

If the Error light is on, some condition occurred that would not allow the printer to continue printing.

Whenever either the Supply or Error light is on, pressing the Voice button will play a message describing the problem. If you are using PCMate Platinum, an error message will be displayed in the Printer Status box of the Virtual Front Panel.

The table below shows all of the printer error messages, along with a description of the problem and some possible solutions. Error messages shaded in gray apply to printer firmware version 3.23.06.12 and earlier. These were changed to clarify that the errors are software errors and do not indicate that the MCB is defective. They are replaced by the SOFTWARE XXX PRESS START message (see the description for details).

Voice Message	Prompt	Description
Knife Error. Press start to continue.	KNIFE DID NOT HOME	The knife did not complete the cut properly, or the knife could not initialize properly. Try again. If this happens frequently or continuously, the knife needs service
The stacker is full. Remove labels from the stacker.	STACKER FULL	The stacker is full. Remove all labels from the stacker. If this error occurs when there are no labels on the stacker, the stacker requires service.
Stacker sensor error. Remove labels from the stacker.	STACKER SENSOR ERROR	This error occurs when the stacker tries to position the platform before printing. The platform position sensor did not respond as expected. This is usually caused by labels blocking the sensor. Remove all labels from the platform and try again. If the error still occurs, the stacker requires service.
Open the top (bottom) print station for a single sided format	OPEN TOP (BOTTOM) PRINthead	The SNAP printers are capable of printing on either the top or bottom printheads, both, or neither (cut only). The unused print station roller(s) must be open.. This eliminates the need to install ink on the unused station. If this error occurs when the bottom station roller is open, the head open sensor is not working.
Lower (Upper) print station error. Printer requires service.	ST1 (2) LOW TEMP READ ERR	This error indicates that the upper or lower printhead temperature is out of normal range. This is generally caused by a disconnected printhead. Check the printhead connections. If the error still occurs, change the printhead. If the error still occurs, replace the printhead cable. If the error still occurs, replace the MCB.

Voice Message	Prompt	Description
Internal error. Press start to continue.	MCB CMD_FRE INDEX ERR MCB CMD_FSE INDEX ERR MCB BAD STACK ERROR MCB KNF FLIT TBL TOO BIG MCB KNIFE STATE TOO BIG MCB KNIFE STATE TOO BIG MCB BEMF MON ST TOO BIG MCB STACKR HM ST TOO BIG MCB KNF HOME ST TOO BIG MCB BEMF CTRL ST TOO BIG MCB SHE BATCH Q OVERFLOW MCB FVE INDEX ERROR MCB ERROR #58 MCB ERROR #59 MCB ERROR #60 MCB ERROR #64 MCB ERROR #68 MCB ERROR #69 MCB ERROR #70 MCB ERROR #91 MCB ERROR #95 MCB ERROR #97 MCB ERROR #98 MCB ERROR #99	These are internal software errors. If one of them occurs, clear the error and continue. If the error continues to occur, report the error and the circumstances that cause it to Avery Dennison Service. These errors are caused by errors in the software and are not caused by hardware failures.
Internal error. Press start to continue.	OUT OF MEMORY IMAGER ERROR 919	These are internal errors similar to the ones above. However, these errors will require power cycling the printer. If the error continues to occur, report the error and the circumstances that cause it to Avery Dennison Service.
Knife cycle error. Increase label length or select a slower print speed.	LBL TOO SHORT FOR SPEED	This error indicates that the label is shorter than the minimum length for the selected print speed. Refer to the Printer Specifications for minimum label lengths. (Minimum label lengths are different for the Sonic Knife. Refer to the Sonic Knife manual.) To run and cut the label, you must either make the label longer or reduce the print speed.
The stock supply roll is empty	STOCK OUT	This error indicates the stock supply roll is empty. If the stock supply roll is not empty, make sure the supply core is firmly held by the arbor clamp. If this error continues to occur, remove the stock roll and press the Start button (the Ready light must be on). The stock arbor should spin counter-clockwise briefly. If it doesn't, the motor or MCB is defective. If it spins and you continue to get the error after re-installing the stock roll, the MCB is defective.

Voice Message	Prompt	Description
The lower (upper) print station ink roll is empty	INK OUT BOTTOM (TOP)	<p>This error indicates that the ink on the specified print station is either missing or broken, or the supply roll is empty.</p> <p>If this error continues to occur even though the ink supply rolls are properly installed, remove the ink rolls and press the Start button. The unwind (supply) arbor should spin counter-clockwise and the rewind (take-up) arbor should spin clockwise briefly. If one or both of the motors does not spin, the motor(s) or MCB are defective. If both motors spin, install a new ink roll. If the error continues to occur with the new ink roll, the MCB is defective.</p>
The lower (upper) print station roller is open	HEAD OPEN BOTTOM (TOP)	<p>This error indicates that either the upper or lower platen roller is open. Close the roller. If the error continues to occur when the roller is closed, check the roller open sensor.</p>
Missed sense mark	MISSED SENSE MARK	<p>The format specifies a sense mark, but no sense mark was found. Possible causes are misalignment of the sensor to the sense mark or incompatibility of the sense mark and the sensor type. Another possible cause is a mismatch between the label length that is set in the format with the actual distance between sense marks on the stock.</p> <p>NOTE: In later versions of code, this message is replaced by the following messages that specify the type of sensor. This gives more information in case the wrong sensor type is selected.</p>
Missed hole sense mark	MISSED HOLE SENSEMARK	<p>The format specifies a hole sense mark, but no sense mark was found. Possible causes are misalignment of the sensor to the sense mark or incompatibility of the sense mark and the sensor type. Another possible cause is a mismatch between the label length that is set in the format with the actual distance between sense marks on the stock. If the format does not specify a hole sense mark, the sensor type override may be set.</p>
Missed top reflective sense mark	MISSED T REFL SENSEMARK	<p>The format specifies a top reflective sense mark, but no sense mark was found. Possible causes are misalignment of the sensor to the sense mark or incompatibility of the sense mark and the sensor type. Another possible cause is a mismatch between the label length that is set in the format with the actual distance between sense marks on the stock. If the format does not specify a top reflective sense mark, the sensor type override may be set.</p>
Missed bottom reflective sense mark	MISSED B REFL SENSEMARK	<p>The format specifies a bottom reflective sense mark, but no sense mark was found. Possible causes are misalignment of the sensor to the sense mark or incompatibility of the sense mark and the sensor type. Another possible cause is a mismatch between the label length that is set in the format with the actual distance between sense marks on the stock. If the format does not specify a bottom reflective sense mark, the sensor type override may be set.</p>

Voice Message	Prompt	Description
Missed contrast sense mark	MISSED CONTR SENSEMARK	The format specifies a contrast sense mark, but no sense mark was found. Possible causes are misalignment of the sensor to the sense mark or incompatibility of the sense mark and the sensor type. Another possible cause is a mismatch between the label length that is set in the format with the actual distance between sense marks on the stock. Also, the contrast sensor option may not be installed. If the format does not specify a contrast sense mark, the sensor type override may be set.
The lower (upper) print head is overheated. Wait until the error light to go out then press start to continue	HEAD 1 (2) OVER TEMP	The printer continuously monitors the temperature of the printhead to ensure it doesn't overheat and damage the printhead. When the printhead temperature reaches a pre-set limit, the printer will stop with this error. Wait for the error light to go out and continue printing. However, it is likely that the error will happen again. Possible solutions are to reduce the print speed or to reduce the amount of copy on the label. If this error happens when the printer is first turned on or does not clear itself within a few minutes, the printhead or MCB may be defective.
Sensor Calibration Error	SENSOR CAL ERROR	When first running a format specifying a particular sensor, or after a missed sense mark error, the printer automatically calibrates the sensor. This error indicates that the printer could not calibrate the sensor. Possible causes are misalignment of the sensor to the sense mark or incompatibility of the sense mark and the sensor type. NOTE: In later versions of firmware, this message is replaced with the ones below, which indicate the selected sensor type. This gives more information in case the wrong sensor type is selected.
Hole sense mark calibration error	HOLE SENSEMARK CAL ERROR	When first running a format specifying a hole sense mark, or after a missed sense mark error, the printer automatically calibrates the sensor. This error indicates that the printer could not calibrate the sensor. Possible causes are misalignment of the sensor to the sense mark or incorrect sensor type
Top reflective mark calibration error	T REFL SENSEMARK CAL ERROR	When first running a format specifying a top reflective sense mark, or after a missed sense mark error, the printer automatically calibrates the sensor. This error indicates that the printer could not calibrate the sensor. Possible causes are misalignment of the sensor to the sense mark or incorrect sensor type
Bottom reflective mark calibration error	B REFL SENSEMARK CAL ERROR	When first running a format specifying a bottom reflective sense mark, or after a missed sense mark error, the printer automatically calibrates the sensor. This error indicates that the printer could not calibrate the sensor. Possible causes are misalignment of the sensor to the sense mark or incorrect sensor type


Voice Message	Prompt	Description
Contrast sense mark calibration error	CONTR SENSEMARK CAL ERROR	When first running a format specifying a contrast sense mark, or after a missed sense mark error, the printer automatically calibrates the sensor. This error indicates that the printer could not calibrate the sensor. Possible causes are misalignment of the sensor to the sense mark or incorrect sensor type. Also, the contrast sensor option may not be installed
Bar code failure	VERIFIER HALT 1 (2) 912 (Note: there is no difference between 1 and 2)	This indicates that the bar code verifier found a bad bar code. The most likely cause is a print quality problem such as an ink wrinkle or a dot out on the printhead. If this error happens on every label, check the printhead for dots out. If this error happens often, but not every label, check the bar code minimum height requirement or lower the ANSI grade.
Communication error. Press start to continue.	BUFFER OVERFLOW SERIAL COMM OVERFLOW	This error indicates that the host computer sent more data than the printer can handle. This error is generally caused by a mismatch in the serial protocol setting (XON/XOFF or RTS/CTS) between the printer and the host, or a cable that does not have the RTS/CTS lines. NOTE: Later versions of firmware use the SERIAL COMM OVERFLOW message to indicate that the problem is in the serial communications.
N/A	TOO MANY FIELDS	The number of fields on the label exceeds the maximum number allowed.
The imager and MCB software versions are not compatible	SOFTWARE MISMATCH	The printer checks to make sure the software versions within the printer are compatible. This error indicates that the versions are not compatible. Upgrade to the latest operating system software.

Voice Message	Prompt	Description
Internal error. Press start to continue.	MCB ERROR #61	These errors are all related to identification devices in the printer or peripherals that are used to read the printer configuration. If one of these errors continues to occur after a power cycle, disconnect all peripherals (stacker, sonic knife, etc.). If the problem still occurs, replace the Frame ID memory. If it still occurs, replace the MCB. If disconnecting the peripherals fixes the problem, reconnect one at a time to determine which one is causing the problem, then replace the printer interface harness.
	MCB ERROR #62	
	MCB ERROR #63	
	MCB ERROR #65	
	MCB ERROR #66	
	MCB ERROR #67	
	MCB ERROR #71	
	MCB ERROR #72	
	MCB ERROR #73	
	MCB ERROR #74	
	MCB ID NOT FOUND	
	MCB ERROR #78	
	MCB ERROR #79	
	MCB ERROR #80	
	FRAME ID NOT FOUND	
	MCB ERROR #84	
	MCB ERROR #85	
	MCB ERROR #86	
	MCB ERROR #87	
	MCB ERROR #88	
	MCB ERROR #89	
	MCB ERROR #88	
	MCB ERROR #89	
	MCB ERROR #91	
	MCB ERROR #92	
	MCB ERROR #93	
	MCB ERROR #94	
	MCB ERROR #100	
Internal error. Press start to continue.	MCB ERROR #96	This error is related to the Security Batch Count feature. It indicates that the Batch Count queue is full, which should never happen. The only way to recover from this is to reset the MCB by removing the battery on the MCB with the power off, then replacing it. This will also reset all the printer settings (print and cut adjust, baud rate, cutter enable, etc.) to their default values.



IF THE RECOMMENDED CORRECTIVE ACTIONS DO NOT RESOLVE THE PROBLEM (S), CONTACT YOUR LOCAL AVERY DENNISON REPRESENTATIVE.

10.0 Mechanical Troubleshooting



There are hazardous moving parts in the printer. Covers must be in place when energized. Service should be performed only by trained service personnel.

10.1 Stock

Problem	Probable Cause	Corrective Action
Stock will not roll smoothly or the stock jumps.	1) Web guides are incorrectly adjusted.	1a) Be sure stock roll is as flat as possible and does not extend over core. 1b) Adjust web guides to touch stock roll, but do not pinch the roll.
	2) Unwind back tension to high.	2a) Reduce the unwind back tension through the virtual panel. 3a) Reduce the print head pressure.
	3) Print head pressure is too high.	
	4) Printer is not threaded correctly.	4a) Check threading diagram and correct as needed.
Stock will not track straight through the printer.	1) Web guides are too loose.	1a) Adjust web guides to touch outer edges of stock with the minimum pressure required.
	2) Material is telescoping of the unwind.	2a) Remove stock supply and tension roll on a flat surface by pulling on the end of the material and holding the core from turning.
	3) Machine not on a level surface.	3a) Level the printer or work table.
	4) Printer is threaded incorrectly.	4a) Check threading diagram and correct.
Stock jams in bridge blade rollers or knife area.	1) Knife not cutting the full width of stock.	1) Refer to section 6.4, Knife Shear Adjustment.
	2) Nip rollers are not turning.	1) Be sure the nip roller is free to rotate and moves easily in the bearing slots. Check for a loose drive gear.



IF THE RECOMMENDED CORRECTIVE ACTIONS DO NOT RESOLVE THE PROBLEM (S), CONTACT YOUR LOCAL AVERY DENNISON REPRESENTATIVE.

10.2 Ink

Problem	Probable Cause	Corrective Action
Ink wrinkles or will not pull smoothly.	1) Ink supply and rewind rolls are misaligned.	1a) Make sure rewind core is equal to or wider than the supply roll width. 1b) Check that the motor is working and has back tension on the supply roll.
	2) Ink buildup on the turn bar(s).	2a) Clean the turn bar(s) with alcohol.
	3) Incorrect ink width.	3a) Use an ink width ¼" (5 mm) wider than the stock being printed on.
	4) Needs more back tension	4a) Increase back tension through the virtual panel.
Ink breaks	1) Head needs cleaning	1a) See cleaning instruction section 5.1
Ink rolls loosely on Rewind core.	1) Ink rewind roll not turning.	1) Check that the motor is working.
	2) Ink rewind roll is too full.	1) Remove ink rewind roll. Replace ink rewind roll with an empty core.

10.3 Print

Problem	Probable Cause	Corrective Action
Poor print – uneven or no print.	1) Print head pressure is too light.	1) Move pressure buttons to increase the pressure. 2) Ensure that both pressure buttons are set to the same height.
	2) Ink rewind roll is too full.	1) Remove ink rewind rolls and replace with empty cores.

10.4 Knife

Problem	Probable Cause	Corrective Action
Knife stops during cut in stock.	1) Knife blades are dull.	1) Refer to section 5.4.1, Removing and Replacing the Knife Assembly.
Stock is popping in front of the knife.	1) Knife blades are dull.	1) Refer to section 5.4.1, Removing and Replacing the Knife Assembly.



IF THE RECOMMENDED CORRECTIVE ACTIONS DO NOT RESOLVE THE PROBLEM (S), CONTACT YOUR LOCAL AVERY DENNISON REPRESENTATIVE.

10.5 Stacker

Problem	Probable Cause	Corrective Action
Stacker fails to move up or down when start button is depressed.	1) Interface cable	1) Not plugged in all the way.
		2) Just installed and needs to be power cycled for printer to identify option installed.
		3) Printer has no batches to print.
Platform cannot find home	1) Sensor unplugged	1) Remove back cover and check connections.
	2) Sensor out of alignment	2) Broken wire or damaged LED
Top of stack is blocking incoming labels	1) Outer bracket bent and needs to be reformed.	1) Check sensor alignment
	2) Sensor not operational	2) Stacker not connected
		3) Loose connection
Stack of labels falling over	2) Static brush position	1) Move static brush up or down
	3) Platform angle	1) Move to other position
	4) Tip stacker	1) Change angle
Label not entering stacker	1) Label jam in knife	1) Clean out label and debris
	2) Nip roller not pulling	1) Worn rubber roller - Replace
		2) Loose set screw or drive gear - Tighten
	3) Soft material / narrow web hitting static brush	1) Adjust the height of the static brush



IF THE RECOMMENDED CORRECTIVE ACTIONS DO NOT RESOLVE THE PROBLEM(S), CONTACT YOUR LOCAL AVERY DENNISON REPRESENTATIVE.

11.0 Appendices

11.1 Fuse Configuration

The main fuse(s) on the SNAP 700 are located inside the AC power entry receptacle. The entry has a fuse drawer that holds the fuse(s) and selects the appropriate line voltage. If the number in the window **DOES NOT** match the AC line voltage intended to be supplied to the printer, **DO NOT** plug the power cord in. Reconfigure as follows:

- 1) Remove the power cord.
- 2) Using a flat blade screwdriver, open the AC entry by lifting the tab just above the voltage indicator window.

WARNING: Attempting to open the AC entry with the AC power cord inserted into it will cause damage to the AC entry.

- 3) Remove the red fuse drawer.
- 4) Remove all fuses and the fuse jumper if it is present.
- 5) Insert into the fuse drawer the correct number and style of fuses and fuse jumper for your application.

Configuration Number One: Line voltage between the range of 90 - 132VAC @ 50 - 60Hz 1 Ph

- 1) Install one 921167 - 10.0A 250V Fast Acting 1/4 x 1 1/4"
- 2) Install one Fuse Jumper

See Figure FUSE1


Configuration Number Two: Line voltage between the range of 180 - 265VAC @ 50 - 60Hz 1 Ph

- 1) Install two 990757 - 6.3A 250V 5 x 20MM

NOTE: The fuse jumper must be removed to install both 5 x 20mm fuses.

The fuses must be between points A and B as shown not B and C.

See Figure FUSE2



- One 1/4 x 1 1/4" Fuse Far Side Two 5 x 20MM Fuses One Each Side
- 6) Reinsert the fuse drawer into the AC entry with the desired voltage up. Close the AC entry and verify the correct voltage is now visible.

11.2 Ink and Stock Transfer Types

Transfer Type values associated with the XT commands.

Value	1.1.1.1.1 Transfer Type
51	Heat Seal & SD-1111 Ink
69	Fabric 2800 & TT-1111 Ink
70	Fabric 2800 & HR-3111 Ink
71	Fabric 2800 & TT-3111 Ink
72	Fabric 2800 & HC-3111 Ink
73	Fabric 2800 & HR-1111 Ink
74	Fabric 2795 & TT-1111 Ink
75	Fabric 2795 & HR-3111 Ink
76	Fabric 2795 & TT-3111 Ink
77	Fabric 2795 & HC-3111 Ink
78	Fabric 2795 & HR-1111 Ink
82	Fabric 2800 & HR-4111 Ink
83	Fabric 2795 & HR-4111 Ink
94	2800 Fabric & GP-1111 Ink
95	2795 Fabric & GP-1111 Ink
96	2795 Fabric & CT-1111 Ink
97	4800 Fabric & CT-1111 Ink
98	4800 Fabric & CT-1114 (Blue)
99	4800 Fabric & GP-1111
100	2395NWT Fabric & CL-1111 (UK)
101	2395NWT Fabric & XC-3111 (UK)
102	2395NWT Fabric & HR-1111 (UK)
103	2495NWT Fabric & CL-1111 (UK)
104	2495NWT Fabric & XC-3111 (UK)
105	2495NWT Fabric & HR-1111 (UK)
106	4000NWT Fabric & CL-1111 (UK)
107	4000NWT Fabric & XC-3111 (UK)
108	4000NWT Fabric & HR-1111 (UK)
109	4002NWT Fabric & CL-1111 (UK)
110	4002NWT Fabric & XC-3111 (UK)
111	4002NWT Fabric & HR-1111 (UK)
112	G.S. Satin & XC-3111 (UK)
113	2012T Fabric & XC-3111 (UK)
114	1021T Fabric & XC-3111 (UK)
115	2800 Fabric & CT-1111
116	591SST Fabric & CT-1111 Ink
117	591SST/601SST Fabrics & CT-1114 Ink

Value	Transfer Type
118	601SST Fabric & CT-1111 Ink
119	591SST/601SST Fabrics & CT-1115 Ink
120	591SST/601SST Fabrics & CT-1117 Ink
121	591SST Fabric & CT-1112 Ink
122	601SST Fabric & CT-1112 Ink
155	4900NWT / 4900HSA & HS1111
156	1800FRA & TW1111
157	1800FRA & GP1111
158	2085NWT / 2495NWT / 2360NWT & HS1111
159	2360NWT / 2800NWT & XC3111
160	2895NWT / 2800NWT & HS1111
161	2895NWT & XC3111
162	2895NWT & HC3111
163	1800MWA & GP1111
164	1800MWA & TW1111
165	604LKP / 601LKP & DS7501 / 7502 / 7504
166	604LKP / 601 LKP & DS7503
167	4800NBC Fabric & HS1011
168	2012T Fabric & HS1111/1112
169	4360NBT Fabric & SD1011
170	4041THS Fabric & HS1111
171	4700TWT Fabric & PL1111
172	4800TST Fabric & CT1111
173	4800TST Fabric & CT1112
174	4800TST Fabric & CT1114
175	4800TST Fabric & CT1115
176	4800TST Fabric & CT5137
177	4800TST Fabric & HS1111
178	770SWT Fabric & CT1112
179	770SWT Fabric & CT1114
180	770SWT Fabric & CT1115
181	770SWT Fabric & CT5137
182	772SWT Fabric & CT1112
183	772SWT Fabric & CT1114
184	772SWT Fabric & CT1115
185	772SWT Fabric & CT5137

11.3 Printer Specifications

Print Method:	5" web thermal transfer two sided printer Speeds: 3 IPS (76.2mm/second), 4.5 IPS (114.3mm/second), 5 IPS (127mm/second), 6 IPS (152.4mm/second), 7 IPS (177.8mm/second), 8 IPS (202.3mm/second), 10 IPS (254mm/second), 12 IPS (304.8mm/second)
Label Size	Standard Feed: Min: 1/2" (12.7mm) web x 1.10" (28mm) feed at 3 IPS (standard stacker) Min: 1/2" (12.7mm) web x 1.10" (28mm) feed at 4.5 IPS (standard stacker) Min: 1/2" (12.7mm) web x 1.10" (28mm) feed at 5 IPS (standard stacker) Min: 1/2" (12.7mm) web x 1.10" (28mm) feed at 6 IPS (standard stacker) Min: 1/2" (12.7mm) web x 1.10" (28mm) feed at 7 IPS (standard stacker) Min: 1/2" (12.7mm) web x 1.185" (28mm) feed at 8 IPS (standard stacker) Min: 1/2" (12.7mm) web x 1.413" (32.1mm) feed at 10 IPS (standard stacker) Min: 1/2" (12.7mm) web x 1.667" (37.4mm) feed at 12 IPS (standard stacker) Short Feed Option: Min: 1/2" (12.7mm) web x 0.750" (19mm) feed at 3 IPS (standard stacker) Min: 1/2" (12.7mm) web x 0.787" (20.1mm) feed at 4.5 IPS (standard stacker) Min: 1/2" (12.7mm) web x 0.853" (25.1mm) feed at 5 IPS (standard stacker) Min: 1/2" (12.7mm) web x 0.960" (25.1mm) feed at 6 IPS (standard stacker) Min: 1/2" (12.7mm) web x 1.079" (26.9mm) feed at 7 IPS (standard stacker) Min: 1/2" (12.7mm) web x 1.185" (26.9mm) feed at 8 IPS (standard stacker) Min: 1/2" (12.7mm) web x 1.413" (32.1mm) feed at 10 IPS (standard stacker) Min: 1/2" (12.7mm) web x 1.667" (37.4mm) feed at 12 IPS (standard stacker) Max: 5 1/8" (130.2mm) web x 5" (127mm) feed (standard stacker) 5:1 web feed to width ratio 5 1/8" (130.2mm) web x 14" (355.6mm) feed No stacker – optional rewind unit or cut without stacking Stacker capacity – coated tape approximately 2,000 labels for full stacker
Print Area	Min: None Max: Up to 5" (127 mm) web x Up to 13.875" (352.4 mm) feed -
Resolution	305 DPI (11.8 dots per mm)
Fonts	True Type – English alphabet, Cyrillic, and Asian characters. 4pt up to 96pt (300 DPI), Supply dependent on 4, 5 and 6 point characters All rotations 0°, 90°, 180°, 270°
Logos	No restriction on number or size per tag (up to maximum image area) All rotations 0°, 90°, 180°, 270°
Care Symbols	Full Ginetex Care Symbol set and full NAFTA / ASTM Care Symbol Set Fully Scaleable All rotations 0°, 90°, 180°, 270°
Justification	Left, Right, and Center field selectable
Stock	Support for blank or pre-printed fabrics, coated or uncoated polyester, woven labels, dip-coated nylons, heat transfer and heat seal tapes. Also support for blank or pre-printed card stock, coated or uncoated, up to 10 point - as well as pressure sensitive labels. Supply Roll: 3" ID (76 mm) cardboard core, Maximum roll size 11.5" O.D. (29 cm)
Interface	Null modem serial cable DB9 F connector


	May require USB/serial adapter May require external Ethernet adapter
Control Panel	Push-button start/stop with 4 LED lights – Ready, Data, Supply, Error voice button
Dimensions	18.5" (470mm) high x 25" (635mm) wide Including stacker x 20.0" (508.0mm) deep
Weight	80 Lbs. (36.3 Kg.)
Electrical	90-132 / 180-265 VAC 50-60Hz - 10 / 6 Amp 1 Ph User selectable
Temperature	40°F (4°C) to 95°F (35°C)
Humidity	5% to 90% non-condensing
Other Features	<ul style="list-style-type: none"> - Downloading of information while machine is operating - Sequenced Fields - Time/Date Stamping (Both month/day/year and day/month/year format) - Life Counts – through PCMate Platinum - Operator adjustable: Contrast – Adjustable on printhead - Cut position, print position and baud rate – Adjustable through PCMate Platinum virtual display - Error Detection of: Stock out, ink out, print head open, feed open, full stacker, stacker jam, and print head over-temperature – with voice commands. - Display: Labels left to be cut and stacked in a batch, batch ID, total life inches, total life cuts - Self Diagnostics – through PCMate Platinum - Missed sense mark detection and correction - Reflective sensor — reads black sense mark printed on front or back of white preprinted stock, full adjustment across the web.
Ink Ribbon	AVERY DENNISON standard thermal colors and widths AVERY DENNISON white plastic core: Maximum Ink O.D. 3.5" Ink widths: With Metric Adapter - 25mm to 127mm metric widths in 5mm increments. With Inch Adapter - 1" to 5" inch widths in ¼" increments.
Options	<ul style="list-style-type: none"> - Short Feed Accessory – reduces the minimum cut label to .75" (19mm) tested to stack as short as 1" feed. Supply dependent based on static properties of the material and environment conditions that may limit the stack height to 1" (25mm). - Contrast or color sensor — Reads sense mark printed on front of preprinted stock. Sense mark or stock may be colored. - Bar code verifier — Scans every bar code printed. Stops printer if a bar code does not scan. - RFID Accessory – Printer can encode stocks that are made with known RFID components. Print speed is 2 or 3 ips to program the RFID component on the fly.
Default Serial Port Setup	The default serial port configuration is 115,200 baud, no parity, 8 data bits, 1 stop bit.

11.4 Factory / Field Installation of Top Sensor Assemblies

These Sensors are alike in mechanical configuration. 05620006 is a Contrast Sensor Assembly only and 05620007 is a Color Contrast Assembly


11.4.1 Installation Procedure

1. Disconnect Power to Printer
2. Disconnect Stacker Interface Cable
3. Remove the Rear Cover (save screws)
4. Remove the existing Sensor Tray Assembly and remove the Web Turn Shaft located on the left side. Replace with the Slotted Web Turn Shaft so that the larger slot is in the upper position as shown. Install the ¼-20 x 3/8 Button Head Cap Screw on the end of the shaft.




5. Create a sub-assembly of the Plastic Collet, the Fiber Optic Slide Shaft, The Fiber Optic Cable and the O-Ring.



Slide the two cables at the rear of the Fiber-Optic Assembly through the Collet as shown. This must be done by sliding one cable through, then sliding cable end of the other cable through parallel to the first. They will not go through together.




6. From the back of the Upright Frame, slide the Collet / Cable Assembly through the $\frac{3}{4}$ diameter hole and secure with (2) 10-32 x $\frac{3}{8}$ Button Head Screws.




7. Install the “O”-Ring in the front groove behind the Fiber-Optic Tube.
(See pics below for clarity)



8. Assemble Sensor Mounting Bracket to Sensor body with two 6-32 x ¼ Button Head Screws.




9. Remove two plastic Jam Nuts from Sensor, slide ends of "Y" Cable through nuts and secure with two 7/32 E-Rings.
10. Insert the threaded Plastic Nuts in the Sensor receptacles, firmly seating the fiber-Optic Cable ends and tighten the Plastic Nuts.



11. Assemble the Sensor / Bracket / Lead Assembly to the Upright Frame using (2) Pem Nuts shown above. Use 10-32 x ¼ Button Head Screws supplied with kit.
12. Assemble Sensor Power Cable to Sensor and plug into MCB Connector labeled "Option Top Color / Contrast".

13. Using the supplied Template, scribe a cutout line on the Rear Cover.



14. Remove the material within this scribed line. Drill corners and use a Dremel Tool or Small Saw.
15. Slide Cover onto Printer. The Cutout should be over the Control Plate on the Sensor. The Sensor may require both horizontal and vertical readjustment to fit below the cutout.
16. Reattach the Rear Cover. Reconnect Stacker connection.
17. When ready to use a sense mark format, program the Sensor per instructions provided with the Sensor.


11.5 Programming the Contrast Sensors

There are two optional contrast sensors available for the SNAP 700 printer. 620006-1 is the standard contrast sensor. It works well in most situations where there is significant contrast between the material background and the sense mark. In situations where there is less contrast between the material and the sense mark, or the material and sense mark are of similar colors, the 620007-1 Color Contrast Sensor may be required.

Both sensors have to be “taught” the difference between the material background and the sense mark. The procedures are similar, and are described below.

11.5.1 Programming the Contrast Sensor

The figure below shows the control panel for the Contrast Sensor. The sensor can detect a light sense mark on dark material (L) or a dark sense mark on light material (D). In each mode, the control switch can be set to RUN or TEACH.



To teach the sensor, thread the printer with the stock to be used. Position the material so that a sense mark is just to the left of the sensor position. Adjust the sensor position across the web so that the sensor lines up with the sense mark.

Set the control switch on the sensor to the TEACH position. If the material has a light sense mark on dark material, set the switch to TEACH L. If the material has a dark sense mark on light material, set the switch to TEACH D.

Press and hold the TEACH button while using the stock advance knob to move the sense mark under and past the sensor.



Make sure that the stock is tight against the web guide. The best way to do this is to press the TEACH button with the left index finger, while applying back tension to the supply roll with the left thumb. This ensures that the stock is in the same position that it will be when the printer is running.

Release the TEACH button. If the Q light flashes rapidly, the sensor did not program correctly. If the process fails repeatedly, the sensor may not be lined up correctly with the sense mark, or there may not be enough contrast between the background and the sense mark.

Move the material so that the sense mark moves back and forth under the sensor. The Q light on the sensor should flash when the sense mark passes under the sensor.


Move the configuration switch to either the RUN L or RUN D position, depending on

the sense mark.

11.5.2 Programming the Color Contrast Sensor

The figure below shows the control panel for the Color Contrast Sensor. The configuration switch has three positions:

Q1 – Teaching mode
Run – Run mode
Run Delay – Do not use



To teach the sensor, thread the printer with the stock to be used. Position the material so that a sense mark is just to the left of the sensor position. Adjust the sensor position across the web so that the sensor lines up with the sense mark.

Set the control switch on the sensor to the Q1 position. Press and hold the TEACH button while using the stock advance knob to move the sense mark under and past the sensor.




Make sure that the stock is tight against the web guide. The best way to do this is to press the TEACH button with the left index finger, while applying back tension to the supply roll with the left thumb. This ensures that the stock is in the same position that it will be when the printer is running.

Release the TEACH button. If the Q/ok light flashes rapidly, the sensor did not program correctly. If the process fails repeatedly, the sensor may not be lined up correctly with the sense mark, or there may not be enough contrast between the background and the sense mark.

Move the material so that the sense mark moves back and forth under the sensor. The Q/ok light on the sensor should flash when the sense mark passes under the sensor.

Move the configuration switch to RUN position.



Item	Part #	Description	1.1.1.1.1.2	Qty
1	594008	Collet, Sensor mount	1	
2	624029	Mount, Fiber Optic	1	
3	624026	Shaft, Turn Bar	1	
4	581316	Bracket, Color Sensor, Mount	1	
5*	581181	Sensor, Contrast, Sick	1	
	581182	Sensor, Color, Sick		
6	990089	10-32 x ¼ BHCS	4	
7	591304	Light Guide, Fiber Optic	6	
8	581124	Cable, Contrast Sensor	1	
9	991305	O-Ring, 5/16 x ½ x .032 Wall	1	
10	990134	¼-20 x 3/8 BHCS	1	
11	620006D	Instructions, Top Color / Contrast Sensor	1	
12	990090	10-32 x 3/8 BHCS	2	

*620006 use part no. 581181


*620007 use part no. 581182

11.6 Factory / Field Installation of High Speed Verifier Assembly


05620008F (Factory) and 05620008 (Field)

11.6.1 Installation Procedure - Mechanical

1. Disconnect Power to Printer.
2. Disconnect Stacker Interface Cable.
3. Remove the Rear Cover (save screws).
4. Install the Bracket, Verifier, Mount Base (621303) on the back of the Upright Frame in the (2) 10-32 Pem Nuts in the upper most right side of the Frame. Secure with (2) 10-32 x $\frac{3}{4}$ Cap Screws.
5. Install the Bracket, Verifier Upright onto the Base Bracket with (2) 8-32 x $\frac{3}{8}$ Flat Head Screws. Tighten securely.




6. Install the Bracket Verifier Mount (621307A) to the Bracket, Verifier Upright (621304) as shown using a washer, set screw and knob. Attach the Verifier to the Assembly, Bracket, Verifier Mount with (2) 6-32 x 3/8 Cap Screws (990016).




11.6.2 Installation Procedure - Electrical

- 1) Facing the back of the Printer, remove the existing connector plate and screws and discard.




- 2) Assemble Internal Verifier Cable into slot and secure with hardware supplied on 581129.




- 3) Mount J1 (5 wire, 10 pin connector) to MCB J7. Mount J2 (3 wire, 10 pin connector) to MCB J11.
- 4) Assemble External Verifier Lead Connector to mating Connector in internal cable (installed in step 2) & mating Connectors to top of Verifier.

11.6.3 Installation – Rear Cover

- 1) Insert the Template supplied into the cover hole below and closest to the above Verifier Bracket Assembly. Bending the Template slightly to match the Cover contour will assure a more accurate location.



- 2) Scribe a line around the inner cutout of the Template.
- 3) Remove the Template and with a small saw or Dremel Tool, remove the material within the scribed line. Slide the Cover onto the Printer to assure a clearance around the Verifier Bracket.



11.7 Warranty Policy

Avery Dennison Retail Information Systems, In-Plant Printing Solutions provides the following warranty policy.

Scope

Warranties against defects from workmanship for equipment and parts manufactured and sold from Miamisburg, OH. Includes time and material except as otherwise noted below.

Time

- New equipment and parts: 6 months
- Refurbished equipment and parts: 90 days
- Warranty period starts when equipment ships from selling location.

General Conditions

Avery Dennison extends warranty coverage under the following conditions.

- Equipment and parts will perform within published specifications. Promised or implied statements by any Avery Dennison employee or representative will not be deemed to vary the terms of the warranty.
- Equipment and parts must be installed and operated according to recommended procedures and operating conditions.
- Consumable elements are not covered. Consumable elements are those that show normal wear from typical equipment usage including, without limitation, printheads, knives, rollers in contact with the web, and sonic units. Avery Dennison reserves the right to determine which elements are defined as “consumable.”
- No customer maintenance may be performed except as directed by qualified Avery Dennison personnel.
- Equipment and parts damaged by negligence or abuse are not covered.
- Avery Dennison US reserves the right in its sole discretion to incorporate any modifications or improvements in the machine system and machine specifications which it considers necessary but does not assume any obligation to make said changes in equipment previously sold.

Equipment Purchased In US and Shipped In US

- Avery Dennison US covers warranty for equipment and parts installed and operated in the Americas (United States, Canada, Mexico, Central America, Caribbean Region, and South America excluding Brazil).
- Outside the US, the local Avery Dennison office is responsible for equipment and parts warranty. Customers must ensure coverage during machine purchase.
- Equipment purchased and exported to regions outside local Avery Dennison office coverage are not covered by warranty. The purchasing agent must acquire a service contract from the Avery Dennison office where the equipment or parts are operated to ensure machine coverage. For example, if an agent purchases a printer in the US, exports to Brazil, and then needs warranty coverage, Avery Dennison Brazil has no obligation to provide warranty coverage. The agent must purchase services from Avery Dennison Brazil.

THE WARRANTIES PROVIDED HEREIN ARE EXCLUSIVE AND ARE IN LIEU OF ANY IMPLIED WARRANTY OF MERCHANTABILITY, FITNESS FOR A PARTICULAR PURPOSE OR OTHER WARRANTY OF QUALITY OR PERFORMANCE, WHETHER EXPRESS OR IMPLIED. EXCEPT THE WARRANTY OF TITLE, IN NO EVENT SHALL AVERY DENNISON BE LIABLE FOR ANY INDIRECT, INCIDENTAL OR CONSEQUENTIAL DAMAGES, EVEN IF AVERY DENNISON HAS BEEN ADVISED OF THE POSSIBILITY OF SUCH DAMAGES.

11.7.1 Service

When ordering machines and supplies in the U.S.A., reference all correspondence to the address below.

AVERY DENNISON Corporation
170 Monarch Lane
Miamisburg, OH 45342

Call: 1-800-214-0872 or (937) 865-2123


For spare parts, requests for service or technical support, contact

AVERY DENNISON Corporation
170 Monarch Lane
Miamisburg, OH 45342

Call: 1-800-214-0872 or (937) 865-2123

For parts and service in other countries, please contact your local AVERY DENNISON supplier.


11.8 Option Menu System Flowchart



VOICE OPTION MENU NAVIGATION CHART


12.0 Electrical Drawings

12.1 Electrical System Schematic




For RFID Printer
use MCB No.
621107RFID TM

12.2 Harness Connections



13.0 Mechanical Assembly Drawings


13.1 Unwind Assembly



Unwind Parts List

ITEM	PART NO.	DESCRIPTION	QTY
1	5623020	SHAFT, QUICK ATTACH UNWIND THREADED	1
2	05724022-1	AXLE SUPPORT	1
3	05623004	SHAFT, CORE LOCATOR	3
4	05990325	SNAP RING, 3/16 "E" RING	6
5	05593002	HUB, OUTER, UNWIND	1
6	05583009	DRAG PLUG, UNWIND	1
7	05991443	SPRING, COMPRESSION	1
8	05989971	5/16:18 X 3/8 LG SET SCREW W/HALF DOG TIP	1
9	05583005	BRACKET, CORE LOCATOR	3
10	05990037	WASHER, #6 SAE	3
11	05990018	6:32 X 3/4 CAP SCREW	3
12	05989987	6-32 E-S NUT	3
13	05623012	SUPPORT, OUTER UNWIND	1
14	05583006	KNOB, UNWIND	1
15	05990052	8:32 X 1/2 CAP SCREW	2
16	05593003	HUB, INNER	1
17	05634051	SHAFT, QUICK ATTACH UNWIND	1
18	05996311	4 SCREW, 4-40 X 5/8 PPHS W/ EXT TOOTH LOCK WASHER	1


13.2 Unwind Assembly RFID 3" / 4"



Unwind Parts List RFID

ITEM	PART NO.	DESCRIPTION	QTY
1	05623020	SHAFT, QUICK ATTACH UNWIND THREADED	1
2	05724022-1	AXLE SUPPORT	1
3	05623004	SHAFT, CORE LOCATOR	3
4	05990325	SNAP RING, 3/16 "E" RING	6
5	05593002	HUB, OUTER, UNWIND	1
6	05583009	DRAG PLUG, UNWIND	1
7	05991443	SPRING, COMPRESSION	1
8	05989971	5/16:18 X 3/8 LG SET SCREW W/HALF DOG TIP	1
9	05623008-1	BRACKET, CORE LOCATOR	3
10	05990037	WASHER, #6 SAE	3
11	05990018	6:32 X 3/4 CAP SCREW	3
12	05989987	6-32 E-S NUT	3
13	05623012	SUPPORT, OUTER UNWIND	1
14	05583006	KNOB, UNWIND	1
15	05990052	8:32 X 1/2 CAP SCREW	2
16	05623001	HUB, INNER UNWIND, 3"	1
17	05623009	ADAPTER, 4" HUB	1
18	05623010	RING, UNWIND HUB	1
19	05990028	6:32X3/8 SOCKET F.HD. SCREW	3
20	05623011	SPRING CLAMP	1
21	05990019	6:32X1/4 B.H. SCREW	1
22	05634051	SHAFT, QUICK ATTACH UNWIND	1
23	05996311	4 SCREW, 4-40 X 5/8 PPHS W/ EXT TOOTH LOCK WASHER	1


13.3 Unwind Motor Assembly



Unwind Motor Parts List

ITEM	PART NO.	DESCRIPTION	QTY
1	05991510	BALL BEARING, 16MM OD X 8 MM ID FLG	2
2	117954	GEAR-RIBBON 75T	1
3	05990327	SNAP RING, 5/16 "E" RING	1
4	117955	GEAR-RIBBON 54T-15T	1
5	05991367	E-RING, 9/64	1
6	05581186	MOTOR, STOCK UNWIND W/EXTENSION	1
7	05991639	M2.6 X 4mm PPHS	3


13.4 Decurler Assembly



Decurler Parts List

ITEM	PART NO.	DESCRIPTION	QTY
1	05624012	SHAFT, DECURLER	1
2	05991376	10-32 X 1/2 PAN PHILLIPS	1
3	117903	BEARING-PLATEN	4
4	05594011	ROLLER, DECURLER	2
5	05990327	SNAP RING, 5/16 "E" RING	2
6	05990067	WASHER, #8 SAE	1
7	05991379	10-32 X 3/8 PHPS	1
8	05991516	PLUG, 5/8 DIA HOLE	1


13.5 Web Guide Assembly



Web Guide Parts List

ITEM	PART NO.	DESCRIPTION	QTY
1	05624057	SHAFT, INK TURN	1
2	05991374	1/4-20 X 1/2 PAN PHILLIPS	1
3	05624089	ASSY, WEB GUIDE MOUNT	2
4	05624050	SHAFT, WEB ADJUST	1
5	05990325	SNAP RING, 3/16 "E" RING	1
6	05196028	KNOB, BLACK (GLOSS) .187 SHAFT HOLE BUSHING SOCKET SET SCREW	1
7	05624049	WEB GUIDE, REAR	1
8	05624047	WEB GUIDE, FRONT	1
9	05990484	1/4:20X1/2 NYLON SLOTTED SCREW	1

13.6 Sensor Tray Assembly




Sensor Tray Parts List

ITEM	PART NO.	DESCRIPTION	QTY
1	05624042	SUPPORT, WEB GUIDE, REAR	1
2	05999100	BUSHING, FL 3/16 X 5/16 X 1/8	4
3	05624009	SHAFT, WEB TURN, STACKER MOUNT	1
4	05624041	SUPPORT, WEB GUIDE	1
5	05624043	SUPPORT, WEB GUIDE, FRONT	1
6	05990051	8:32 X 3/8 CAP SCREW	4
7	05624034	PIN, IDLER GEAR	1
8	05990028	6:32X3/8 SOCKET F.HD. SCREW	1
9	05990120	1/4:20 X 1/2 CAP SCREW	3
10	05990133	1/4:20 X 3/4 F H SCREW	2
11	05444018U	DRIVE, SPUR 20T GEAR	1
12	05624032	SHAFT, SENSOR ADJUST, UPPER	1
13	05354009	GEAR, DRIVEN	2
14	05196028	KNOB, BLACK (GLOSS) .187 SHAFT HOLE BUSHING SOCKET SET SCREW	1
15	05624044	BRIDGE BLADE, BOTTOM	1
16	05990055	8:32X3/8 F. H. SCREW	2
17	05990066	8:32X1/4 BTN. SCREW	6
18	05624030	BLOCK, LED MOUNT	1
19	05581128	SENSOR, REFLECTIVE HARNESSSED	2
20	05989985	WASHER, #2 SAE	2

ITEM	PART NO.	DESCRIPTION	QTY
21	05989994	2-56 X 1/2 HEX SOCKET HD CAP SCREW	2
22	05624045	BRIDGE BLADE, TOP	1
23	05624033	SHAFT, SENSOR ADJUST, LOWER	1
24	05624031	BLOCK, SENSOR MOUNT	1
25	05554005	DRIVE, WEB GUIDE ADAPTER	1
26	05626016	SHAFT, ECCENTRIC TURN BAR	1
27	05626017	TUBE, ECCENTRIC TURN BAR	1
28	05626019	INSERT, ECCENTRIC FOIL SHAFT	1
29	113742	SUPPORT-ADJ ROLLER-M01460-TOOL T-10222	1
30	113744	ECCENTRIC-ADJ #2 M01460-TOOL 10222	1
31	05990017	6:32 X 1/2 CAP SCREW	1
32	05990312	KNOB, SZ 6 THUMB SCREW	1
33	999083012	M3 X 6mm PHIL PAN HEAD SCREW	1

13.7 Sensor Tray RFID Assembly



* Items 1 and 4 ordered as one Assembly, Part no. 05624087 – Assy, Rear Support


**Items 3 and 4 ordered as one Assembly, Part no. 05624088 – Assy, Front Support

Parts shown exploded for clarity purposes

Sensor Tray RFID Parts List

ITEM	PART NO.	DESCRIPTION	QTY	ITEM	PART NO.	DESCRIPTION	QTY
1	5624042	SUPPORT, WEB GUIDE, REAR	1	22	5624030	BLOCK, LED MOUNT	1
2	5624041	SUPPORT, WEB GUIDE	1	23	5624031	BLOCK, SENSOR MOUNT	1
3	5624043	SUPPORT, WEB GUIDE, FRONT	1	24	5554005	DRIVE, WEB GUIDE ADAPTER	1
4	5999100	BUSHING, FL 3/16 X 5/16 X 1/8	4	25	5990017	6:32 X 1/2 CAP SCREW	1
5	5354009	GEAR, DRIVEN	2	26	5990312	KNOB, SZ 6 THUMB SCREW	1
6	5624033	SHAFT, SENSOR ADJUST, LOWER	1	27	5581128	SENSOR, REFLECTIVE HARNESSSED	2
7	5624032	SHAFT, SENSOR ADJUST, UPPER	1	28	5989985	WASHER, #2 SAE	2
8	5624034	PIN, IDLER GEAR	1	29	5989994	2-56 X 1/2 HEX SOCKET HD CAP SCREW	2
9	05444018U	DRIVE, SPUR 20T GEAR	1	30	5626016	SHAFT, ECCENTRIC TURN BAR	1
10	5990028	6:32X3/8 SOCKET F.HD. SCREW	1	31	5626017	TUBE, ECCENTRIC TURN BAR	1
11	5990120	1/4:20 X 1/2 CAP SCREW	3	32	5626019	INSERT, ECCENTRIC FOIL SHAFT	1
12	5990051	8:32 X 3/8 CAP SCREW	4	33	113742	SUPPORT-ADJ ROLLER-M01460-TOOL T-10222	1
13	5196028	KNOB, BLACK (GLOSS) .187 SHAFT HOLE BUSHING SOCKET SET SCREW	1	34	113744	ECCENTRIC-ADJ #2 M01460-TOOL 10222	1
14	5624058	BRIDGE BLADE, BOTTOM	1	35	5989530	3MM X 6MM PAN HD PHIL HD SC	3
15	5624059	BRIDGE BLADE, TOP	1	36	05624109-1	BRACKET, RFID ANTENNA (ADJ F. TO B.)	1
16	5990055	8:32X3/8 F. H. SCREW	2	37	5990050	8:32 X 1/4 CAP SCREW	2
17	5990066	8:32X1/4 BTN. SCREW	6	38	5624069	GUARD, RFID ANTENNA	1
18	5624009	SHAFT, WEB TURN, STACKER MOUNT	1	39	126547	PWA, RFID ANTENNA 902-928 MHZ (REPLACES 126354)	1
19	5990133	1/4:20 X 3/4 F H SCREW	2	40	5624064	SPACER, RFID ANTENNA	2
20	5990374	COLLAR, 1/2"	2	41	5991074	3 X 12MM FLAT HEAD SCREW	2
21	5990484	1/4:20X1/2 NYLON SLOTTED SCREW	2	42	125731	BOX, ANTENNA	1

13.8 Top Print Head Assembly




Top Printhead Parts List

ITEM	PART NO.	DESCRIPTION	QTY
1	05625033	PRINT HEAD HOUSING, LOWER	1
2	05625012	ASSEMBLY, LATCH PRINT HEAD	1
3	05581161	FAN, PRINT HEAD HARNESSSED	1
4	05585005	SCREW, SPECIAL HEAD LOCK	2
5	05581111	POT, CONTRAST CONTROL	1
6	05991572	ROLL PIN, 3/32 X 3/8	2
7	05625040	PRESSURE ADJUSTER	1
8	05625021	BUSHING, SPRING MOUNT	1
9	05625032-1	PIN, SPRING GUIDE	1
10	05991604	SPRING, COMPRESSION C0300-0380-500-M	1
11	05990329	E-RING, 7/32	1
12	05990079	10:32 X 1/4 CAP SCREW	1
13	05625129	ASSEMBLY, PRINT HEAD MOUNT	1
14	05625026	LOCK PIN, HD	1
15	05990019	6:32X1/4 B.H. SCREW	1
16	05625020	SPRING, PRINT HEAD RETAINER	2
17	05357040	PLATE, SPRING CAM, LONG	2
18	05357036	PLATE, SPRING CAM, MEDIUM	2
19	05625043	CLIP, HOLD DOWN	1
20	05625041-1	KNOB, CLIP	1
21	05991593	SCREW, 6-32 X 3/16 LG BUTTON HEAD	1
22	05625036	PIN, PRINT HEAD PIVOT	2
23	05625039	STICKER, CONTRAST POT	1
24	05990192	6:32 X 1/2 BUTTON HEAD SCREW	2
25	05990051	8:32 X 3/8 CAP SCREW	2
26	05990513	TIE WRAP, TY523M SMALL	1
27	05991597	SPRING, EXT	2
28	05625010	TURN BAR, INK	1
29	05990055	8:32X3/8 F. H. SCREW	2
30	05621124	CABLE, PRINT HEAD 700, BOTTOM	1

Bottom Printhead Parts List

ITEM	PART NO.	DESCRIPTION	QTY
1	05625034	PRINT HEAD HOUSING, LOWER	1
2	05625012	ASSEMBLY, LATCH PRINT HEAD	1
3	05581161	FAN, PRINT HEAD HARNESSSED	1
4	05585005	SCREW, SPECIAL HEAD LOCK	2
5	05581111	POT, CONTRAST CONTROL	1
6	05991572	ROLL PIN, 3/32 X 3/8	2
7	05625040	PRESSURE ADJUSTER	1
8	05625021	BUSHING, SPRING MOUNT	1
9	05625032-1	PIN, SPRING GUIDE	1
10	05991604	SPRING, COMPRESSION C0300-0380-500-M	1
11	05990329	E-RING, 7/32	1
12	05990079	10:32 X 1/4 CAP SCREW	1
13	05625129	ASSEMBLY, PRINT HEAD MOUNT	1
14	05625026	LOCK PIN, HD	1
15	05990019	6:32X1/4 B.H. SCREW	1
16	05625020	SPRING, PRINT HEAD RETAINER	2
17	05357040	PLATE, SPRING CAM, LONG	2
18	05357036	PLATE, SPRING CAM, MEDIUM	2
19	05625043	CLIP, HOLD DOWN	1
20	05625041-1	KNOB, CLIP	1
21	05991593	SCREW, 6-32 X 3/16 LG BUTTON HEAD	1
22	05625036	PIN, PRINT HEAD PIVOT	2
23	05625039	STICKER, CONTRAST POT	1
24	05990192	6:32 X 1/2 BUTTON HEAD SCREW	2
25	05990051	8:32 X 3/8 CAP SCREW	2
26	05990513	TIE WRAP, TY523M SMALL	1
27	05991597	SPRING, EXT	2
28	05625010	TURN BAR, INK	1
29	05990055	8:32X3/8 F. H. SCREW	2
30	05621124	CABLE, PRINT HEAD 700, BOTTOM	1


13.10 Print Head Assembly



Printhead Parts List

ITEM	PART NO.	DESCRIPTION	QTY
1	05625094-1	ASSEMBLY, 700 PRINT HEAD, 5 INCH	1
2	05625050	GUARD, PRINT HEAD	1


13.11 Platen Roller Assembly



Platen Roller Parts List

ITEM	PART NO.	DESCRIPTION	QTY
1	05581130	SENSOR, OPTICAL SLOTTED, HARNESSSED	1
2	05990014	2:56 HEX NUT	2
3	05625037	SHAFT, SWING ARM	1
4	05990090	10:32 X 3/8 BTN. SCREW SOCKET HEAD	1
5	05625042-1	ASSEMBLY, SWING ARM	1
6	117903	BEARING-PLATEN	6
7	05625015	SHAFT, PLATEN ROLLER	1
8	05625046	SPACER, SWING ARM GUIDE	1
9	05990327	SNAP RING, 5/16 "E" RING	2
10	05625014	ROLLER, MOLDED, PLATEN, RED	1
11	05990067	WASHER, #8 SAE	1
12	05990068	WASHER, #8 LOCKWASHER	1
13	05991454	8-32 X 1/4 THUMB SCREW	1
14	05991608	SPRING, EXTENSION	1


13.12 Ink Arbor Assembly



Ink Arbor Parts List

ITEM	PART NO.	DESCRIPTION	QTY
1	05626088-1	ASSY, INK ARBOR	1
2	05626005	CAP, INK ARBOR	1
3	05626003	SHAFT, ADJUSTMENT	1
4	05991543	FOIL KNOB, G-12	1
5	05990058	8-32 X 1/4 KNURLED CUP POINT	1
6	05626011	CORE STOP, FRONT	1
7	05626012	CORE STOP, REAR	1
8	05990057	8-32 X 1/8 KNURLED CUP POINT	2
9	05991567	SCREW, 8-32 X 3/16 NYLON SET SCREW	1


13.13 Ink Unwind / Rewind Motor(s) Assembly



Ink Unwind / Rewind Motor(s) Parts List

ITEM	PART NO.	DESCRIPTION	QTY
1	05621237	KIT, FRAME ASSEMBLY, SNAP 700	1
2	05991510	BALL BEARING, 16MM OD X 8 MM ID FLG	2
3	05626088-1	ASSEMBLY, INK ARBOR SHAFT	2
4	117954	GEAR-RIBBON 75T	2
5	05990327	SNAP RING, 5/16 "E" RING	2
6	126468	MOTOR-RIBBON	2
7	05991639	M2.6 X 4mm PPHS	6
8	117955	GEAR-RIBBON 54T-15T	2
9	05991367	E-RING, 9/64	2


13.14 Drive Assembly



Drive Parts List

ITEM	PART NO.	DESCRIPTION	QTY
1	05624016	BRACKET, END DRIVE	2
2	05999001	R6FF BEARING	2
3	05624039	BRACKET, STRIPPER WIRE MOUNT	1
4	05624017	ROLLER, GRIT (MAIN DRIVE)	1
5	05624020-1	SHAFT, IDLER ROLLER	1
6	05624190-1	ASSY, FEED ROLLER	1
7	05624022	BRACKET, STRIPPER, LOWER	1
8	05990281	WASHER, 1/2X3/4X.015 SHIM	2
9	05990328	MUST BE ROHS SNAP RING, 1/2 "E" RING	2
10	05624021-1	PLUG, SPRING LOCK	2
11	05990136	1/4:20 X 1/4 KNURLED CUP POINT	4
12	05989979	10:32 X 1 KNURLED CUP POINT	1
13	05990104	10:32 E-S NUT	1
14	05105023K	IMPRESSION ADJ KNOB/SS KIT	1
15	05990055	8:32X3/8 F. H. SCREW	10
16	05448010	STATIC BRUSH	1
17	05990066	8:32X1/4 BTN. SCREW	4
18	05990079	10:32 X 1/4 CAP SCREW	2
19	05624046	BRACKET, STRIPPER UPPER	1
20	05624178	COVER, FEED GUARD, SNAP 700	1
21	05624015	BRACKET, BASE, DRIVE MODULE	1
22	05991626	COMPRESSION SPRING, .360 OD X .059 WIRE X .69	2

13.15 Knife Assembly



* Items 5 & 7 ordered as a kit only, includes both torsion springs items 18 & 19.


Parts shown exploded for clarity purposes

* See Addendum II for Knife Parts List of machines with short feed option*

Knife Assembly Parts List

ITEM	PART NO.	DESCRIPTION	QTY
1	05627307	BRKT, SHORT FEED MOUNT, REAR	1
2	05999001	R6FF BEARING	2
3	05999097	BUSHING, FL 1/4 X 3/8 X 3/16	1
4	05627009	BASE, KNIFE SUPPORT	1
5	05627091	ASSEMBLY, GROUND ROTARY	1
6	05627308	BRKT, SHORT FEED MOUNT, FRONT	1
7	05357093	ASSEMBLY, STATIONARY KNIFE	1
8	05627014	BRIDGE BLADE, KNIFE OUTPUT	1
9	05990066	8:32X1/4 BTN. SCREW	4
10	05627013	BRIDGE BLADE, KNIFE	1
11	05990019	6:32X1/4 B.H. SCREW	2
12	05517021	BLOCK, SHEAR ADJUST	1
13	05990015	6-32 X 1/4 CAP SCREW	1
14	05627024	BRACKET, BRIDGE BLADE	2
15	05991253	SCREW, 6-32 BUTTON HEAD CS X 3/16	4
16	05357095	ASSEMBLY, OILER MOUNT	1
17	05990055	8:32X3/8 F. H. SCREW	6
18	05197319	TORSION SPRING, RIGHT	1
19	05357029	TORSION SPRING BACK, DC KNIFE	1
20	05990025	6:32 X 1/4 SET SCREW	2
21	05990120	1/4:20 X 1/2 CAP SCREW	2

13.16 Nip Roller Assembly




* See Addendum II for Nip Roller Parts List of machines with short feed option*

Nip Roller Parts List

ITEM	PART NO.	DESCRIPTION	QTY
1	05624023	BRACKET, NIP ROLLER MOUNT	1
2	05584033	BRACKET, NIP ROLLER OUTER	1
3	05999098	BUSHING, 3/16 X 1/4 X 3/8	2
4	05624024	ROLLER, NIP DRIVE, MOLDED	1
5	05624025	ROLLER, NIP	1
6	05999165	BUSHING, 3/16 X 1/4 X 1/4	1
7	05999076	BEARING, 3/16 X 1/4 X 5/8 OIL NS IMPREG BUSHING	1
8	05990325	SNAP RING, 3/16 "E" RING	4
9	05991523	SPRING, COMP 500/600 NIP ASSEMBLY	2
10	05990424	4-40 X 3/8" SH CAP SCREW	2
11	05624038	BRACKET, STRIPPER	1
12	05448010	STATIC BRUSH	1
13	05991373	8-32 X 1/4 PAN PHILLIPS	2
14	05991454	8-32 X 1/4 THUMB SCREW	2
15	05991377	10-32 X 3/4 PAN PHILLIPS	2


13.17 Knife / Drive Motors Assembly



Knife / Drive Motors Assembly arts List

ITEM	PART NO.	DESCRIPTION	QTY
1	05594004	SHAFT, NIP ROLLER DRIVE	1
2	05584028	GEAR, NIP 26T, 32P	1
3	05584027	GEAR, IDLER 22T, 32P	2
4	05624037	GEAR, NIP IDLER, ALTERED	1
5	05990326	SNAP RING, 1/4 "E" RING	2
6	05990327	SNAP RING, 5/16 "E" RING	4
7	05587017	STANDOFF, KNIFE MOTOR	3
8	05245026	STEPPER MOTOR, HARNESSSED	2
9	05990080	10:32 X 3/8 CAP SCREW	6
10	05991642	DRIVE, BEAM COUPLING	1
11	05587018	ASSEMBLY, KNIFE DRIVE SHAFT	1
12	05581130	SENSOR, OPTICAL SLOTTED, HARNESSSED	1
13	05585016	GEAR, 38T DRIVE 300 DPI	1
14	05991422	4-40 X 1/4 PAN HD PHILLIPS	2
15	05990006	4:40 X 1/4 CAP SCREW	1
16	117902	GEAR-PLATEN	2


13.18 Knife Drive Motor Assembly RFID



Knife Drive Motor Assembly RFID Parts List

ITEM	PART NO.	DESCRIPTION	QTY
1	05627029	STANDOFF, KNIFE MOTOR	3
2	05627032	STEPPER, MOTOR HARNESSSED	1
3	05990081	10:32X1/2 CAP SCREW	3
4	05627030	DRIVE, BEAM COUPLING, ALTERED	1
5	05587018	ASSEMBLY, KNIFE DRIVE SHAFT	1
6	05581130	SENSOR, OPTICAL SLOTTED, HARNESSSED	1
7	05991422	4-40 X 1/4 PAN HD PHILLIPS	2
8	05627031	SHAFT, INERTIAL SLUG	1
9	05990077	8:32 X 1/2 KNURLED CUP POINT	2


13.19 RFID Reader Assembly



RFID Reader Parts List

ITEM	PART NO.	DESCRIPTION	QTY
1	05591141	POWER SUPPLY, 24V HARNESED	1
2	05621023-1	BRACKET, SIRIT / THINGMAGIC	1
3	05999787	4M 8MM SHCS	2
4	129383	MODULE, UHF RFID, THINGMAGIC M5E-C	1
5	05991422	4-40 X 1/4 PAN HD PHILLIPS	4


13.20 Covers Assembly



Covers Parts List

ITEM	PART NO.	DESCRIPTION	QTY
1	05621237	KIT, FRAME ASSEMBLY, SNAP 700	1
2	05621202A	COVER, FRONT, 700 SNAP 1/1	1
3	05581205	COVER, REAR, 500	1
4	05991376	10-32 X 1/2 PAN PHILLIPS	7
5	05991508	8-32 X 1/2 FLANGED BUTTON HEAD SCREW	10
6	05341210	FEET, 1 1/2" DIA RUBBER	6
7	05991374	1/4-20 X 1/2 PAN PHILLIPS	8
8	05621235-1	INSERT, SNAP 700 COVER	1


13.21 Cooling Fans Assembly



Cooling Fans Part List

ITEM	PART NO.	DESCRIPTION	QTY
1	05621237	KIT, FRAME ASSEMBLY, SNAP 700	1
2	05621206-2	BRACKET, MCB SUPPORT	1
3	05621007	BRACKET, EXIT FAN CHUTE	1
4	05991372	6-32 X 1/4 PAN PHILLIPS	4
5	05621004	BRACKET, EXIT FAN MOTOR	1
6	05621134	FAN, HARNESSSED 12V	1
7	05581104-1	FAN, 12V HARNESSSED	1
8	05991638	SCREW, 6-32 X 1.250 PHCS	6
9	05621006	BRACKET, AIR DEFLECTOR	1
10	05991379	10-32 X 3/8 PHPS	2


13.22 Stacker Assembly (Sheet 1 of 2)



Stacker Parts List (Sheet 1 of 2)

ITEM	PART NO.	DESCRIPTION	QTY
1	05628010	FRAME, STACKER, 700	1
6	05588029	BRACKET, DIODE MOUNT, FRONT	1
7	05588031	COVER, LABEL SENSOR	2
11	05628003	ASSY, PLATFORM MOUNT	1
12	05991378	10-32 X 3/8 PHILLIPS FLAT HEAD SCREW	2
13	05628005	ASSY, PLATFORM LABEL	1
14	05990325	E-RING, 3/16	2
15	05628006	SHAFT, LOCK	1
16	05990486	SNAP RING, 3/8 E-RING	1
17	05991439	SPRING, PIN LOCK	1
18	05996159	SWITCH ROCKER, SPDT	1
21	05989986	4-40 ES NUT	3
22	05581177	HARNESS, DOWN STACKER ASSY, PROGRAMMED WITH GEAR	1
36	05628033-1	COVER, DOWN STACKER, 700	1
37	05991442	8-32 X 3/8 PHILLIPS FLAT HEAD SCREW	2
39	05628012	SPACER, STACKER SLIDE	2

13.23 Stacker Assembly (Sheet 2 of 2)



Stacker Parts List (Sheet 2 of 2)

ITEM	PART NO.	DESCRIPTION	QTY
1	05628010	FRAME, STACKER, 700	1
2	05628004	BRACKET, STACKER MOUNT	1
3	05990273	WASHER, #10 BELLEVILLE	1
4	05990104	10-32 E-S NUT	2
5	05990148	1/4-20 ES NUT	1
6	05588029	BRACKET, DIODE MOUNT, FRONT	1
7	05588031	COVER, LABEL SENSOR	2
8	05588028	BRACKET, DIODE MOUNT REAR	1
9	05991455	10-32 X 5/8 THUMB SCREW	1
10	05588001A	PLATFORM SLIDE, ALT	1
11	05628003	ASSY, PLATFORM MOUNT	1
12	05991378	10-32 X 3/8 PHILLIPS FLAT HEAD SCREW	2
13	05628005	ASSY, PLATFORM LABEL	1
14	05990325	E-RING, 3/16	2
15	05628006	SHAFT, LOCK	1
16	05990486	SNAP RING, 3/8 E-RING	1
17	05991439	SPRING, PIN LOCK	1
18	05996159	SWITCH ROCKER, SPDT	1
19	05991510	BALL BEARING , 16mm O.D. x 8mm I.D. FLG	2
20	05628002	SHAFT, MAIN DRIVE	1

ITEM	PART NO.	DESCRIPTION	QTY
21	05989986	4-40 ES NUT	3
22	05581177	HARNESS, DOWN STACKER ASSY, PROGRAMMED WITH GEAR	1
23	05991372	6-32 X 250 PHILLIPS PAN HEAD SCREW	2
24	05990038	6-32 HEX NUT	2
25	117954	GEAR-RIBBON 75T	1
26	117955	GEAR-RIBBON 54T-15T	1
27	05990327	E-RING, 5/16	3
28	05991367	E-RING, 9/64	1
29	05990051	8-32 X 3/8 SHCS	4
30	05991419	DRIVE, SPROCKET #25, 16T	2
31	05588037	ASSY, CHAIN TENSION	1
32	05991418	SPROCKET, STACKER, 10T	2
33	05991419A	SPROCKET, STACKER 16T ALTERED	1
34	05990058	8-32 X 1/4 KNURLED CUP POINT	2
35	05990069	8-32 HEX NUT	8
36	05628033-1	COVER, DOWN STACKER, 700	1
37	05991442	8-32 X 3/8 PHILLIPS FLAT HEAD SCREW	2
38	05628011	CHAIN, STACKER DRIVE	1
39	05628012	SPACER, STACKER SLIDE	2
z			

14.0 Addendum I – Handling Procedures

OPERATIONS

PRINTER WEIGHT: The printer weighs are 75 pounds (34 Kg) or less and requires a table of sufficient quality and strength to handle this load. The AVERY DENNISON SNAP® printer line requires an area with the approximate dimensions of 72" wide x 30" deep x 32" high (1.8 m x 76 cm x 81 cm). The host PC (if used) and any printer options will increase the required area. AVERY DENNISON recommends using an industrial type worktable approved for use for such loads.

LOCATION CONSIDERATIONS: The AVERY DENNISON SNAP printer line is designed for easy operator accessibility to the printer controls and components. Select your AVERY DENNISON SNAP printer's location to meet the following criteria:

1. Choose an area that maintains optimum flow of your product and allows for the operator's comfort. Consider the physical demands being placed on the operator with respect to height of the table on which the printer will be placed, the amount of space around the printer, and the operator's accessibility to the printer.
2. While AVERY DENNISON has designed the printer to be reasonably quiet, select an area where repetitious noise from printing and cutting processes is acceptable and where heat generated by the printer can be quickly dissipated.

CAUTION: It is each customer's or end user's responsibility to make sure that the workstation created for the AVERYDENNISON SNAP printer line meets the recommended requirements to ensure optimal operation of the printer.

MAINTENANCE

PRINT HEAD CLEANING AND MAINTENANCE: Follow the recommended procedure in accordance with the printer User's Manual.

PRINT HEAD CLEANING SUPPLIES: AVERY DENNISON recommends below supplies for use in cleaning print heads.

05921341: Starter TT Printer Cleaning Pack

1 bottle alcohol, 3 alcohol pads, 5 cotton swabs, 1 Velcro pad

05241149: Anti-static glove

05241132: Static wrist strap

SUPPLIES

STORAGE CONDITIONS: Store label tapes and thermal transfer ribbons in original wrapper out of direct sunlight at 45°F (7°C) to 95°F (35°C), 20% to 85% relative humidity.

SHELF LIFE: Two (2) years from date of manufacture.

RESPIRATORY PROTECTION: None is specifically recommended for handling this product however.

VENTILATION: None is specifically recommended for handling this product.

EYE PROTECTION: Eye protection is recommended in support of facility eye protection program.

OTHER PROTECTIVE EQUIPMENT: None is specifically recommended for handling this product.

DISPOSAL METHOD: Material is currently not considered to be a hazardous waste material. Waste material may be disposed of through routine handling for any sanitary/municipal waste material in accordance with federal, state and local laws.

The information contained herein is believed to be reliable but AVERY DENNISON makes no representations concerning the accuracy or correctness of the data. This product, the related media and supplies, like any other should be tested by the customer/user thoroughly under end user conditions to ensure the product meets the particular requirements. Independent results may vary.


15.0 Addendum II – Short Feed

Machines equipped with short feed option use different parts noted after O-ring replacement instructions. Machines with short feed option have ability to handle labels as short as .66" long.


O-rings on short feed nip rollers are wear items and require occasional changing. It is recommended to change all O-rings at same time.

15.1 Short Feed O-Ring Replacement

1. Separate knife assembly from nip roller assembly by removing (2) nip assembly mount screws (shown below).



2. Remove bridge blade and static brush from nip roller assembly by loosening (2) static brush thumb screws. Remove any worn or damaged o-rings from rubber rollers and replace with new o-rings. Rubber rollers are secured to nip roller brackets by tension from o-rings. Stretch o-rings over nip roller brackets, then direct rubber roller ends to ½ slots on nip roller brackets. See below.



15.3 Short Feed Part List

ITEM	PART NO.	DESCRIPTION	QTY
1	05197319	TORSION SPR FRONTDC KNIFE	1
2	05357029	TORSION SPR BACK, DC KNIFE	1
3	05357093	ASSEMBLY, STATIONARY KNIFE	1
4	05448010	STATIC BRUSH	1
5	05517021	BLOCK, SHEAR ADJUST	1
6	05627024	BRACKET, BRIDGED BLADE	2
7	05627091	ASSEMBLY, GROUND ROTARY	1
8	05627301	SHAFT, SHORT FEED NIP EXT	1
9	05627302	FLEX BEAM COUPLING	1
10	05627303	BRKT, SHORT FEED NIP STRIPPER	1
11	05627304	O-RING, SHORT FEED	4
12	05627305	BRKT, SHORT FEED FRONT	1
13	05627306	BRKT, SHORT FEED REAR	1
14	05627307	BRKT, SHORT FEED MOUNT, REAR	1
15	05627308	BRKT, SHORT FEED MOUNT, FRONT	1
16	05627309	SHAFT, SHORT FEED INNER IDLER	1
17	05627310	SHAFT, SHORT FEED OUTER IDLER	1
18	05627311	SHAFT, SHORT FEED INNER DRIVE	1
19	05627312	SHAFT, SHORT FEED OUTER DRIVE	1
20	05627313	BRKT, SHORT FEED STACKER MOUNT	1
21	05627318	ASSY, KNIFE GUARD	1
22	05627319	BASE, SHORT FEED KNIFE SUPPORT	1
23	05990015	6-32 X 1/4 SHCS	1
24	05990025	6-32 X 1/4 SET SCREW	2
25	05990055	8-32 X 3/8 FHCS	6
26	05990057	8-32 X 1/8 KNURLED CUP POINT	4
27	05990066	8-32 X 1/4 BHCS	2
28	05991253	6-32 X 3/16 BHCS	4
29	05991454	8-32 X 1/4" THUMB SCREW	2
30	05991523	SPRING, COMP 500/600 NIP ASSEMBLY	4
31	05991651	6-32 X 7/8 BHCS	2
32	05999001	R6FF BEARING	2
33	05999097	BUSHING, FL 1/4 X 3/8 X 3/16	1

Avery Dennison Technical Support Product / Services Installation Report

Customer:		Failure Report #:	(For office use)
Address:		Service Report #:	
		Failure Reported By:	
		Date:	
		Model #:	
Contact:		Serial #:	
Phone #:		Mfg. Date:	(For office use)

Out of Box Failure	Yes		No		Within 30 Days of installation	Yes		No	
Total Inches		---			Within Warrantee	Yes		No	
Total Cuts		---			If within Warrantee, which month	.			

Failure Codes

Code	Description	Code	Description
100	Normal user Adjustments only, not a failure.	106	Non-operating (bad) electronic part, not visually broken.
101	Could not repair, (return machine to engineering).	107	Non-operating (bad) mechanical part, not visually broken.
102	Visually broken or bent electrical parts.	108	Re-adjustment required internally to function.
103	Visually broken or bent mechanical part.	109	Re-adjustment required externally to function.
104	Missing Electrical part, machine won't function.	110	Part fell off or disconnected, put back on, still good.
105	Missing mechanical part, machine won't function.	111	Missing Supplies or Formats

Description of Failure

16.0 Revision Record

Revision	Date	Description
3.1	23-JUL-2010	Added Ink Supply Roll Caution note to section 2.4, page 14 Added section 5.5, Rubber Roller, Replacement, page 58 Added Revision History page, page 144
4.0	06-APR-2011	Added support for RFID printers in the parts pages Added updates to many of the parts pages for the latest production parts Updated text to support both SNAP 700 and SNAP 700 RFID Added addendum for Printer and Supplies Handling.
4.1	28-NOV-2012	Removed CE mark from manual as not required Update FCC ID and moved to page 2 Moved WEEE symbol to page 2
4.2	01-MAY-2013	ECN 3009453 Added short feed addendum pages 147-150 Updated print head assemblies pages 118-121
4.3	29-JUL-2013	Up Dated minimum label size in Specifications
4.4	14-FEB-2014	Added webserver instructions Updated assembly drawings to CB version of printer
4.5	17-DEC-2014	ECN 3010206 Added section 2.5.6 Added Unwind Assembly – Two Shaft Design (New) BOM Added Unwind Assembly – RFID 3”/4” Two Shaft Design (New) BOM
4.6	19-NOV-2015	Updated assembly drawings to show BOM on separate pages
4.7a	22-SEP-2016	Updated classification in accordance with Avery Dennison policy. Updated networking. Updated stacker items. Updated parts page item numbers for legibility. Updated document with TUV recommendations.
4.8	28-FEB-2017	Updated Declaration of Conformity RFID error printouts



Avery Dennison
170 Monarch Lane
Miamisburg, OH 45342

1-800 543-6650 (In the U.S.A.)

1-800-387-4740 (In Canada)

www.averydennison.com