

# READ THIS FIRST

Before you use your Monarch® Pathfinder® Ultra®  
*Platinum 6039™* printer:

1. Fully charge the battery.  
You *must* charge the battery when you receive the printer, even if you do not use it right away.
2. Insert the battery into the printer.  
Refer to the *Operator's Handbook* for more information on using the battery.

The first time you use your printer after removing it from the box you *must*:

1. Turn on the printer.
2. Wait for the desktop to load completely (approximately 30 seconds).

**Important:** Do **not** touch the display or push any buttons on the keypad until the desktop has finished loading. The printer may lock up.

3. Press and hold the on/off button until the printer restarts and wait for the desktop to reload.  
If the printer locks up, repeat Step 3.

Your printer is now ready to use.

